

[illegible][illegible]

TSDRIVER
Table of contents

N 2
- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00

Page 0

| | | |
|-----|------|-------------------------------------|
| (1) | 499 | DRIVER TABLES |
| (1) | 790 | UNIT INITIALIZATION ROUTINE |
| (1) | 935 | TEST NBA (NEED BUFFER ADDRESS) |
| (1) | 1034 | START I/O OPERATION |
| (2) | 1233 | NOP AND SIMULATED FUNCTIONS |
| (2) | 1268 | READ HARDWARE FUNCTIONS |
| (2) | 1353 | WRITE FUNCTIONS |
| (2) | 1420 | POSITIONING FUNCTIONS |
| (2) | 1563 | FORMAT COMMANDS |
| (2) | 1615 | CONTROL COMMANDS |
| (2) | 1641 | INITIALIZE AND GET STATUS |
| (2) | 1693 | COMPLETION PROCESSING |
| (2) | 1740 | HARDWARE COMMAND EXECUTOR |
| (3) | 2170 | TS11/TS04 INTERRUPT SERVICE ROUTINE |
| (3) | 2241 | TIMEOUT HANDLER |
| (3) | 2358 | TS11/TS04 REGISTER DUMP ROUTINE |


```
0000 1 .TITLE TSDRIVER - VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DRIVER
0000 2 .IDENT 'V04-000'
0000 3
0000 4
0000 5 *****
0000 6 *
0000 7 * COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0000 8 * DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0000 9 * ALL RIGHTS RESERVED.
0000 10 *
0000 11 * THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0000 12 * ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0000 13 * INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0000 14 * COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0000 15 * OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0000 16 * TRANSFERRED.
0000 17 *
0000 18 * THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0000 19 * AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0000 20 * CORPORATION.
0000 21 *
0000 22 * DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0000 23 * SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0000 24 *
0000 25 *
0000 26 *****
0000 27
0000 28
0000 29 : E. E. OUYANG 2-APR-79
0000 30
0000 31 : MODIFIED BY:
0000 32
0000 33 : V03-017 MMD0317 Meg Dumont, 25-Jul-1984 11:13
0000 34 : Add support for the UCBSL_MEDIA_ID field
0000 35
0000 36 : V03-016 MMD0304 Meg Dumont, 27-Jun-1984 15:24
0000 37 : Fix to 296 so that only READ REVERSE into BOT returns ENDOFFILE
0000 38
0000 39 : V03-015 MMD0296 Meg Dumont, 3-May-1984 9:45
0000 40 : Fix to fix MMD0265 we really must return SS$_NORMAL not
0000 41 : anyother error code.
0000 42
0000 43 : V03-014 ROW0355 Ralph O. Weber 30-APR-1984
0000 44 : Modify processing of the IOSM_OPPOSITE modifier so that its
0000 45 : use is limited to IOS$_REREADN and IOS$_REREADP functions by
0000 46 : code, rather than by comments. This provides some protection
0000 47 : against accidental misuse of the IOSM_CLSEREXCP bit which is
0000 48 : relivant only for tape class driver tapes but which shares the
0000 49 : same modifier bit as IOSM_OPPOSITE.
0000 50
0000 51 : V03-013 RAS0300 Ron Schaefer 27-Apr-1984
0000 52 : Add DEV$_NNM characteristic to DECHAR2 so that these
0000 53 : devices will have the 'node$' prefix.
0000 54
0000 55 : V03-012 MMD0265 Meg Dumont, 22-Mar-1984 15:28
0000 56 : Fix so that reverse into BOT returns SS$_ENDOFFILE like other
0000 57 : drivers.
```

```
0000 58 :
0000 59 :
0000 60 : V03-011 MMD0225 Meg Dumont, 23-Jan-1984 11:27
0000 61 : Deleted the check in the drivers' unit init routine which
0000 62 : checked on powerfail to see if the TS SUBSYSTEM was ready
0000 63 : before reloading registers etc.. This check was no
0000 64 : longer necessary since Robert added the code TEST_NBA which
0000 65 : makes sure the controller is available before we allow
0000 66 : the QIO to start on the device.
0000 67 :
0000 68 : V03-010 MMD0219 Meg Dumont, 9-Jan-1984 13:59
0000 69 : Instead of checking for powerfail at TS_INIT check
0000 70 : for command buffer allocated. Fix for support of
0000 71 : switchable unibus
0000 72 :
0000 73 : V03-009 ROW0258 Ralph O. Weber 17-NOV-1983
0000 74 : The Paul Painter Memorial Enhancement
0000 75 : Named for one of the unfortunate customers who suffered much
0000 76 : to determine the great UCBSL_MT_RECORD secret while trying to
0000 77 : create a user-written magtape driver, this change eliminates
0000 78 : use of the device dependent field, UCBSL_MS_RECORD in favor of
0000 79 : the device independent field, UCBSL_RECORD.
0000 80 :
0000 81 : V03-008 ROW0213 Ralph O. Weber 20-AUG-1983
0000 82 : Change basing for device-dependent UCB from UCBSL_DP_LINK+4 to
0000 83 : a field independent UCBSL_LCL_TAPE_LENGTH. This allows the
0000 84 : device-independent UCB to be altered without having to edit
0000 85 : this module.
0000 86 :
0000 87 : V03-007 BLS0234 Benn Schreiber 9-Aug-1983
0000 88 : Use general addressing mode for EXESREAD_TODR.
0000 89 :
0000 90 : V03-006 KDM0060 Kathleen D. Morse 14-Jul-1983
0000 91 : Change references to IPR TODR to use cpu-dependent
0000 92 : routine, EXESREAD_TODR.
0000 93 :
0000 94 : V03-005 RLRDPATH1 Robert L. Rappaport 31-May-1983
0000 95 : Allow UCB to include new DUAL PORT extension by
0000 96 : changing base of where we begin the private TSDRIVER
0000 97 : extension from UCBSL_DPC+4 to UCBSL_DP_LINK+4.
0000 98 :
0000 99 : V03-004 RLRTRACE Robert L. Rappaport 11-Feb-1983
0000 100 : Add conditionally assembled trace facility.
0000 101 :
0000 102 : V03-003 RLR52135 Robert L. Rappaport 22-Dec-1982
0000 103 : Prevent reverse into BOT from returning SS$_OPINCOMPL.
0000 104 :
0000 105 : V03-002 RLR0001 Robert L. Rappaport 15-July-1982
0000 106 : Prevent logging two errors for each soft retry.
0000 107 :
0000 108 : V03-001 KDM0002 Kathleen D. Morse 28-Jun-1982
0000 109 : Added $DCDEF, $DEVDEF, $DYNDEF, $PRDEF and $VADEF.
0000 110 :
0000 111 : TS11/TS04 MAGTAPE DRIVER
0000 112 :
0000 113 : MACRO LIBRARY CALLS
0000 114 :
```



```
0000 115
0000 116      $CRBDEF      ;DEFINE CRB OFFSETS
0000 117      $DCDEF      ;DEFINE DEVICE TYPES
0000 118      $DDBDEF      ;DEFINE DDB OFFSETS
0000 119      $DEVDEF      ;DEFINE DEVICE TYPES
0000 120      $DPTDEF      ;DEFINE DPT OFFSETS
0000 121      $DYNDEF      ;DEFINE DYNAMIC DATA STRUCTURE TYPES
0000 122      $EMBDEF      ;DEFINE EMB OFFSETS
0000 123      $IDBDEF      ;DEFINE IDB OFFSETS
0000 124      $IODEF      ;DEFINE I/O FUNCTION CODES
0000 125      $IRPDEF      ;DEFINE IRP OFFSETS
0000 126      $MTDEF      ;DEFINE MAGTAPE STATUS BITS
0000 127      $PRDEF      ;DEFINE PROCESSOR REGISTERS
0000 128      $SSDEF      ;DEFINE QIO STATUS RETURN CODES
0000 129      $UCBDEF      ;DEFINE UCB OFFSETS
0000 130      $VADEF      ;DEFINE VIRTUAL ADDRESS FIELDS
0000 131      $VECDEF      ;DEFINE INTERRUPT DISPATCH VECTOR OFFSETS
0000 132      $WCBDEF      ;DEFINE WCB OFFSETS
0000 133
0000 134      :
0000 135      : LOCAL MACROS
0000 136      :
0000 137      : EXECUTE HARDWARE COMMAND AND BRANCH ON RETRIABLE ERROR CONDITION
0000 138      :
0000 139
0000 140      .MACRO EXHC      BDST,HC
0000 141      .IF NB      HC
0000 142      MOVZBL      #CD'HC,RO      ;GET HARDWARE COMMAND INDEX
0000 143      .ENDC
0000 144      BSBW      HCEX      ;CALL HARDWARE COMMAND EXECUTION ROUTINE
0000 145      .WORD      BDST-.-2      ;BRANCH ADDR. ON ERROR CONDITION
0000 146      .ENDM      EXHC
0000 147
0000 148      ; MACRO TO CALL G*IOC$LOADUBAMAPA
0000 149
0000 150      .MACRO LOADUBAA
0000 151      JSB      G*IOC$LOADUBAMAPA
0000 152      .ENDM      LOADUBAA
0000 153
0000 154
0000 155      :
0000 156      : GENERATE HARDWARE COMMAND TABLE ENTRY AND CASE TABLE INDEX SYMBOL
0000 157      :
0000 158
0000 159      .MACRO GENHC      HC
0000 160      CD'HC=<.-HCTAB>/2      ;DEFINE TABLE INDEX SYMBOL
0000 161      .WORD      HC      ;HARDWARE COMMAND TABLE ENTRY
0000 162      .ENDM      GENHC
0000 163
0000 164
0000 165      :
0000 166      : LOCAL SYMBOLS
0000 167      :
0000 168
0000 169      : TS11/TS04 COMMAND PACKET DEFINITION
0000 170      :
0000 171      :
```

```
00000000 0000 172
0000 173
0000 174
0000 175
0000 176
0000 177 $DEF MS_CPHD .BLKW 1
0002 178 _VIELD MS_CPHD,0,<-
0002 179 <COD,5>,-
0002 180 <2>,-
0002 181 <IE,,M>,-
0002 182 <MOD,4>,-
0002 183
0002 184 <SWB,,M>,-
0002 185 <OPP,,M>,-
0002 186 <CVC,,M>,-
0002 187 <ACK,,M>,-
0002 188
0002 189 $DEF MS_BACT .BLKW 1
0004 190 $DEF MS_BA1 .BLKW 1
0006 191 $DEF MS_CNT .BLKW 1
0008 192
0008 193 $DEF MS_MBA0 .BLKW 1
000A 194 $DEF MS_MBA1 .BLKW 1
000C 195 $DEF MS_LNTH .BLKW 1
000E 196 $DEF MS_CHWD .BLKW 1
0010 197 _VIELD MS_CHWD,4,<-
0010 198 <ERI,,M>,-
0010 199 <EAI,,M>,-
0010 200 <ENB,,M>,-
0010 201 <ESS,,M>,-
0010 202
0010 203
0010 204
0010 205 : TS11/TS04 MESSAGE PACKET DEFINITION
0010 206 :
0010 207
0010 208
0010 209 $DEF MS_MHD .BLKW 1
0012 210 _VIELD MS_MHD,0,<-
0012 211 <COD,5>,-
0012 212 <FMT,3>,-
0012 213 <CLS,4>,-
0012 214 <RSR,3>,-
0012 215 <ACK,,M>,-
0012 216
0012 217 $DEF MS_LNH .BLKW 1
0014 218
0014 219 $DEF MS_RBPC .BLKW 1
0016 220 $DEF MS_XSRO .BLKW 1
0018 221 _VIELD MS_XSRO,0,<-
0018 222 <EOT,,M>,-
0018 223 <BOT,,M>,-
0018 224 <WLK,,M>,-
0018 225 <PED,,M>,-
0018 226 <VCK,,M>,-
0018 227 <IE,,M>,-
0018 228 <ONL,,M>,-
```

:RESET PC?????
:COMMAND PACKET HEADER
:
:COMMAND CODE FIELD
:B5-B6 ALWAYS 0 FOR TS04
:INTERRUPT ENABLE
:COMMAND MODE FIELD(B11-B8)
:B8=REVERSE & B9=RETRY
:SWAP BYTES BIT(B12)
:OPPOSITE BIT(B13)
:CLEAR VOLUME CHECK(B14)
:ACKNOWLEDGE BIT(B15)
:
:BUS ADDRESS(B15-B0) OR COUNT
:BUS ADDRESS B17-B16(RIGHT JUST)
:BYTE COUNT
:FOR WRITE CHARACTERISTIC DATA
:MESSAGE BUFFER ADDR. WRD 1
:MESSAGE BUFFER ADDR. WRD 2
:MESSAGE BUFFER LENGTH(ALWAYS 14.)
:CHARACTERISTIC WORD
:
:ENABLE MESSAGE BUFFER RELEASE INTERRUPTS
:ENABLE ATTENTION INTERRUPTS
:USED WITH ESS BIT**
:ENABLE SKIP TAPE MARKS STOP

:MESSAGE PACKET
:MESSAGE HEADER WORD
:MESSAGE CODE FIELD
:FORMAT FIELD
:CLASS CODE FIELD
:RESERVED FIELD
:MESSAGE ACKNOWLEDGE BIT(B15)
:
:MESSAGE LENGTH WORD
:HIGH BYTE=0,LOW BYTE=1010(LENGTH)
:RESIDUAL BYTE/POSITION COUNT
:EXTENDED STATUS REGISTER 0
:
:END OF TAPE DETECTED(B0)
:BEGINNING OF TAPE(B1)
:WRITE LOCKED(B2)
:PHASE ENCODED DRIVE(B3)
:VOLUME CHECK(B4)
:INTERRUPT WAS ENABLED(B5)
:DEVICE ON-LINE(B6)


```
0018 229 <MOT,,M>,- :TAPE MOVING ON LAST COMMAND(B7)
0018 230 <ILA,,M>,- :ILLEGAL ADDRESS(B8)
0018 231 <ILC,,M>,- :ILLEGAL COMMAND(B9)
0018 232 <NEF,,M>,- :NON-EXECUTABLE FUNCTION(B10)
0018 233 <WLE,,M>,- :WRITE LOCK ERROR(B11)
0018 234 <RLI,,M>,- :RECORD LENGTH LONG(B12)
0018 235 <LET,,M>,- :LOGICAL END OF TAPE(B13)
0018 236 <RLS,,M>,- :RECORD LENGTH SHORT(B14)
0018 237 <TMK,,M>,- :TAPE MARK DETECTED(B15)
0018 238 >
0018 239 $DEF MS_XSR1 .BLKW 1 :EXTENDED STATUS REGISTER 1
001A 240 _VIELD MS_XSR1,0,<-
001A 241 <MTE,,M>,- :
001A 242 <UNC,,M>,- :
001A 243 <POL,,M>,- :
001A 244 <POS,,M>,- :
001A 245 <POS,,M>,- :
001A 246 <POS,,M>,- :
001A 247 <POS,,M>,- :
001A 248 <POS,,M>,- :
001A 249 <POS,,M>,- :
001A 250 <POS,,M>,- :
001A 251 <POS,,M>,- :
001A 252 <POS,,M>,- :
001A 253 <POS,,M>,- :
001A 254 <POS,,M>,- :
001A 255 <POS,,M>,- :
001A 256 <POS,,M>,- :
001A 257 <POS,,M>,- :
001A 258 <POS,,M>,- :
001A 259 <POS,,M>,- :
001A 260 <POS,,M>,- :
001A 261 <POS,,M>,- :
001A 262 <POS,,M>,- :
001A 263 <POS,,M>,- :
001A 264 <POS,,M>,- :
001A 265 >
001A 266 $DEF MS_XSR2 .BLKW 1 :EXTENDED STATUS REGISTER 2
001C 267 _VIELD MS_XSR2,0,<-
001C 268 <DTP,8>,- :
001C 269 <XSK,,M>,- :
001C 270 <WCF,,M>,- :
001C 271 <CAF,,M>,- :
001C 272 <CAF,,M>,- :
001C 273 <CAF,,M>,- :
001C 274 <CAF,,M>,- :
001C 275 <CAF,,M>,- :
001C 276 >
001C 277 $DEF MS_XSR3 .BLKW 1 :EXTENDED STATUS REGISTER 3
001E 278 _VIELD MS_XSR3,0,<-
001E 279 <RTB,,M>,- :
001E 280 <LXS,,M>,- :
001E 281 <NOI,,M>,- :
001E 282 <DCK,,M>,- :
001E 283 <CRF,,M>,- :
001E 284 <REV,,M>,- :
001E 285 <OPI,,M>,- :
```



```
001E 286 <LMX,M>.- ;TAPE LIMIT EXCEEDED(B7)
001E 287 <FEC,8>.- ;B15-B8, FATAL ERROR CODE(U-DIAGNOSTIC)
001E 288 >
001E 289
001E 290 $DEFEND MS
0000 291
6CE9300B 0000 292 MEDIA_ID_TS11 = *X<6CE9300B>
0000 293
0000 294 ; TS11/TS04 TSSR TERMINATION CLASS CODES
0000 295
0000 296
00000000 0000 297 TCC_NML=0 ;NORAML TERMINATION
00000001 0000 298 TCC_ATN=1 ;ATTENTION CONDITION
00000002 0000 299 TCC_TSA=2 ;TAPE STATUS ALERT
00000003 0000 300 TCC_FNR=3 ;FUNCTION REJECT
00000004 0000 301 TCC_REM=4 ;RECOVERABLE ERROR(TAPE MOVED)
00000005 0000 302 TCC_REN=5 ;RECOVERABLE ERROR(TAPE NOT MOVED)
00000006 0000 303 TCC_UER=6 ;UNRECOVERABLE ERROR(TAPE POSI. LOST)
00000007 0000 304 TCC_FTL=7 ;FATAL CONTROLLER ERROR
0000 305
0000 306
0000 307 ; FATAL CLASS (FC) CODES IN TSSR
0000 308
0000 309
00000000 0000 310 FCC_IDF=0 ;INTERNAL DIAG. FAILURE
00000001 0000 311 FCC_CPE=1 ;IO SEQUENCE CROM PARITY ERROR
00000002 0000 312 FCC_UPE=2 ;U-PROCESSOR CROM PARITY ERROR OR OTHER
00000003 0000 313 FCC_LAP=3 ;LOSS OF AC POWER DETECTED
0000 314
0000 315
0000 316 ; TS11/TS04 MESSAGE CODES IN MS_MHD_COD
0000 317
0000 318
00000010 0000 319 MSG_END=*0020 ;END
00000011 0000 320 MSG_FAL=*0021 ;FAIL
00000012 0000 321 MSG_ERR=*0022 ;ERROR
00000013 0000 322 MSG_ATN=*0023 ;ATTENTION
00000014 0000 323 MSG_LOG=*0024 ;LOG (NOT USED)
0000 324
0000 325
0000 326 ; CLASS CODE FOR MESSAGE CODES (MS_MHD_CLS VALUES)
0000 327
0000 328
0000 329 ;**WHEN MSG TYPE=ATTENTION**
00000000 0000 330 CLS_ONF=0 ;ON OR OFFLINE
00000001 0000 331 CLS_MDF=1 ;MICRO DIAG. FAILURE
0000 332 ;**WHEN MSG TYPE=FAIL**
00000000 0000 333 CLS_PTB=0 ;PACKET BAD(SERIAL BUS PARITY ERROR)
00000001 0000 334 CLS_OTHER=1 ;OTHERS
00000002 0000 335 CLS_WLN=2 ;WRITE LOCK ERROR OR NON-EXECUTABLE FUNCTION
00000003 0000 336 CLS_MDE=3 ;MICRO DIAGNOSTIC ERROR
0000 337
0000 338
0000 339 ; TS11/TS04 HARDWARE COMMAND MODES/CODES
0000 340
0000 341
0000 342 ; INTERRUPT ENABLE & ACKNOWLEDGE
```

```
00000000 0000 343 HC_NOP=0 ;SIMULATED NOP (REAL NO OPERATION)
00000000 0000 344 HC_PAK=HC_NOP ;SIMULATED PACK ACKNOWLEDGE
00000000 0000 345 HC_WCK=HC_NOP ;SIMULATED WRITE CHECK
00000000 0000 346 HC_WKR=HC_NOP ;SIMULATED WRITE CHECK REVERSE
00000000 0000 347 HC_RPS=HC_NOP ;SIMULATED READ IN PRESET
00000000 0000 348 HC_SCH=HC_NOP ;SIMULATED SET CHARACTERISTICS
0000 349
0000 350
0000C081 0000 351 HC_RDN=*00001!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* READ NEXT (FORWARD)
0000C181 0000 352 HC_RDP=*00401!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* READ PREVIOUS (REVERSE)
0000C281 0000 353 HC_RRP=*01001!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* REREAD PREVIOUS (SPACE RE
0000C381 0000 354 HC_RRN=*01401!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* REREAD NEXT (SPACE FWD, R
0000C084 0000 355 HC_WRC=*00004!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;+ WRITE CHARACTERISTICS
0000C085 0000 356 HC_WRD=*00005!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* WRITE DAT
0000C285 0000 357 HC_WDR=*01005!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* WRITE DATA RETRY (SPACE R
0000 358 ; WRITE DATA)
0000C086 0000 359 HC_WSM=*00006!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* WRITE SUBSYSTEM MEMORY
0000C088 0000 360 HC_SRF=*00010!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ SPACE RECORDS FORWARD
0000C188 0000 361 HC_SRR=*00410!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ SPACE RECORDS REVERSE
0000 362 ;HC_STF=*01010!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ SKIP TAPE MARKS FORWARD
0000 363 ;HC_STR=*01410!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ SKIP TAPE MARKS REVERSE
0000 364 ;**NOTE** SKIP TAPE MARK COMMANDS ARE SIMULATED BY SKIP RECORD COMMANDS**
0000C088 0000 365 HC_STF=*00010!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ SPACE TAPE MARK FORWARD
0000C188 0000 366 HC_STR=*00410!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ SPACE TAPE MARKS REVERSE
0000C488 0000 367 HC_RWD=*02010!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ REWIND
0000C089 0000 368 HC_WTM=*00011!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- WRITE TAPE MARK
0000C189 0000 369 HC_ERS=*00411!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- ERASE
0000C289 0000 370 HC_WTR=*01011!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- WRITE TAPE MARK RETRY (SP
0000 371 ; ERASE, WRITE TAPE MARK)
0000C08A 0000 372 HC_BRL=*00012!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- MESSAGE BUFFER RELEASE
0000C18A 0000 373 HC_UNL=*00412!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- REWIND AND UNLOAD
0000C28A 0000 374 HC_CLN=*01012!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- CLEAN
0000C08B 0000 375 HC_DRI=*00013!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- DRIVER INITIALIZE
0000C08F 0000 376 HC_GST=*00017!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- GET STATUS IMMEDIATE
0000 377 ;**NOTE**
0000 378 ; * => DATA XFR
0000 379 ; + => (SPECIAL)
0000 380 ; $ => POSITION
0000 381 ; - => FORMAT, CONTROL, INITIALIZE, & STATUS
0000 382
0000 383
0000 384 ; DEFINE DEVICE DEPENDENT UNIT CONTROL BLOCK OFFSETS
0000 385 ;
0000 386
0000 387 $DEFINI UCB
0000 388
0000 389 $VIELD UCB,0,<- ;DEV. DEP. STATUS BITS IN UCBSW_DEVSTS
0000 390 <MS_FEF,,M>,- ;TAPE IS PAST ONE TAPE MARK
0000 391 <MS_SWAP,,M>,- ;*SWAP BYTES FOR COMPATIBILITY MODE
0000 392 <MS_IWR,,M>,- ;*INHIBIT WRITE RETRIES
0000 393 <MS_SER,,M>,- ;SELECT ERROR HAS OCCURRED????
0000 394 <MS_RWD,,M>,- ;UNIT IS REWINDING
0000 395 <MS_RDPR,,M>,- ;REQUEST DATAPATH FLAG
0000 396 <MS_SWE,,M>,- ;DOING SOFTWARE EMULATION
0000 397 <MS_NER,,M>,- ;NO ERROR RECOVERY
0000 398 <MS_UMD,,M>,- ;USER MODE DIAGNOSTIC REQUEST
0000 399 <MS_RSP,,M>,- ;REWIND/SPACE IN PROGRESS
```



```
0000 400 <MS_LBA,,M>,- ;LOADING BUFFER ADDR. INTO TS04
0000 401 <MS_RPI,,M>,- ;RPOSITIONING IN PROGRESS
0000 402 <MS_VCK,,M>,- ;VOLUME CHECK
0000 403 <MS_RIP,,M>,- ;RETRY IN PROGRESS FLAG
0000 404
0000 405
0000 406
0000 407
0000 408
0000 409
0000 410
0000 411
0000 412
0000 413
0000 414
0000 415
0000 416
0000 417
0000 418
0000 419
0000 420
0000 421
0000 422
0000 423
0000 424
0000 425
0000 426
0000 427
0000 428
0000 429
0000 430
0000 431
0000 432
0000 433
0000 434
0000 435
0000 436
0000 437
00000084 0000 438
0004 439
0006 440
000A 441
000A 442
000E 443
00C0 444
00C2 445
00C4 446
00C4 447
00C4 448
00C4 449
00C4 450
00C4 451
00C4 452
00C4 453
00C4 454
00C4 455
00C4 456

; ** STATUS BITS DEFINED ELSEWHERE **
; ** IN UCBSL_DEVDEPEND:
; ** MTSM_PARITY=1, IF EVEN; 0, IF ODD
; ** MTSV_FORMAT=MTSK_DEFAULT/NORMAL11/CORDMP11/NORMAL15
; ** MTSV_DENSITY=MTSK_PE_1600/MTSK_NRZI-800
; ** MTSM_BOT=TAPE IS AT BOT
; ** MTSM_EOF=TAPE AT EOF
; ** MTSM_EOT=TAPE AT EOT
; ** MTSM_HWL=HARDWARE WRITE LOCKED
; ** MTSM_LOST=TAPE POSITION LOST
; ** IN UCBSW_STS:
; ** UCBSM_TIM=TIMEOUT ENABLED
; ** UCBSM_INT=INTERRUPT EXPECTED
; ** UCBSM_ERLOGIP=ERRORLOG IN PROGRESS
; ** UCBSM_CANCEL=CANCEL I/O
; ** UCBSM_ONLINE=UNIT ONLINE
; ** UCBSM_POWER=POWER FAILED WHILE UNIT BUSY
; ** UCBSM_TIMEOUT=UNIT TIME OUT
; ** UCBSM_INTTYPE=RECEIVER INTERRUPT, IF SET
; ** UCBSM_BSY=UNIT IS BUSY
; ** UCBSM_MOUNTING=DEVICE IS BEING MOUNTED
; ** UCBSM_DEADMO=DEALLOCATE AT DISMOUNT
; ** UCBSM_VALID=VOLUME IS SOFTWARE VALID
; ** UCBSM_UNLOAD=UNLOAD VOLUME AT DISMOUNT
; ** IN UCBSL_DEVCHAR:
; ** DEVS_M_SWL=SOFTWARE WRITE LOCKED
; ** .....
; NEW EXTENSION TO UCB FOR TS11/TS04
;
;UCBSK_LCL TAPE LENGTH
$DEF UCBSW_MS_SPACNT .BLKW 1 ;SPACING COUNT
$DEF UCBSL_MS_TSPT1 .BLKL 1 ;PTR. TO TS04 BUFFER IN
;NON-PAGED POOL
$DEF UCBSL_MS_TSPT2 .BLKL 1 ;CORRESPONDING UNIBUS ADDR.
$DEF UCBSW_MS_TSPT3 .BLKW 1 ;COMMAND PTR FOR TS11/TS04
$DEF UCBSW_MS_TSBA .BLKW 1 ;TS11/TS04 DEVICE REGISTER(TSBA)
$DEF UCBSW_MS_TSSR .BLKW 1 ;TS11/TS04 DEVICE REGISTER(TSSR)
_VIELD MS TSSR,1,- ;TS11/TS04 STATUS REGISTER(B0 UNUSED)
<TEC,3>,- ;TERMINATION CLASS CODE FIELD
<FC,2>,- ;FATAL ERROR CLASS CODE FIELD
<OFL,,M>,- ;DEVICE IS OFF-LINE(B6)
<SSR,,M>,- ;SUBSYSTEM READY(B7)
<A16,,M>,- ;BUFFER ADDRESS BIT 16
<A17,,M>,- ;BUFFER ADDRESS BIT 17
<NBA,,M>,- ;NEED BUFFER ADDRESS(B10)
<NXM,,M>,- ;NON-EXISTENT MEMORY(B11)
<RMR,,M>,- ;REGISTER MODIFICATION REFUSED(B12)
<SPE,,M>,- ;SERIAL BUS PARITY ERROR(B13)
```

```
00C4 457 <UPE,,M>,- ;UNIBUS PARITY ERROR(B14)
00C4 458 <SC,,M>,- ;SPECIAL CONDITION(B15)
00C4 459 >
00C4 460 ;**FATAL ERROR CONDITION: UPE!SPE!NXM!NBA
00C4 461 $DEF UCBSW_MS_XC .BLKW 1 ;BYTES XFERRED OR RECORDS/FILES SKIPPED
00C6 462 $DEF UCBSB_MS_DPN .BLKB 1 ;DATA PATH NUMBER
00C7 463 $DEF UCBSB_MS_PER .BLKB 1 ;PURGE ERROR IF BIT 0 SET
00C8 464 $DEF UCBSL_MS_DPR .BLKL 1 ;DATA PATH REGISTER USED
00CC 465 $DEF UCBSL_MS_FMPR .BLKL 1 ;FINAL MAP REGISTER
00D0 466 $DEF UCBSL_MS_PMPR .BLKL 1 ;FINAL-1(PREVIOUS) MAP REGISTER
00D4 467 ;**NOTE**LAST 1 LONGWORD IS USED DURING
00D4 468 ;****POWERFAIL REPOSITIONING
00D4 469 $DEF UCBSL_MS_NMPR .BLKL 1 ;FINAL+1(NEXT) MAP REGISTER
00D8 470 $DEF UCBSL_MS_OMPR .BLKL 1 ;COPY OF VEC$W_MAPREG(LONGWORD IN CRB)
00DC 471 $DEF UCBSL_MS_TIMEOUT .BLKL 1 ;Timeout value for function in progress
00E0 472 $DEF UCBSQ_MS_TMP1 .BLKQ 1 ;TEMP FOR UCBSW_BCNT,BOFF, and SVAPTE
00E8 473 $DEF UCBSL_MS_TMP2 .BLKL 1 ;TEMP. FOR CRB$C_INTD+VEC$W_MAPREG
00EC 474 $DEF UCBSQ_MS_BUF SVAPTE ;AREA TO SAVE PARAMETERS TO MAP MESSAGE
000000F4 00EC 475 .BLKQ 1 ;BUFFER IN UNIBUS SPACE
00F4 476 $DEF UCBSL_MS_TPOSITN .BLKL 1 ;TAPE POSITION AT POWERFAIL
00F8 477 $DEF UCBSW_MS_MHD .BLKW 1 ;MESSAGE PACKET**COPY IN UCB**
00FA 478 $DEF UCBSW_MS_LNH .BLKW 1 ;MESSAGE LENGTH WORD
00FC 479 $DEF UCBSW_MS_RBPC .BLKW 1 ;RESIDUAL BYTE/POSITOIN COUNT
00FE 480 $DEF UCBSW_MS_XSR0 .BLKW 1 ;EXTENDED STATUS REGISTER 0
0100 481 $DEF UCBSW_MS_XSR1 .BLKW 1 ;EXTENDED STATUS REGISTER 1
0102 482 $DEF UCBSW_MS_XSR2 .BLKW 1 ;EXTENDED STATUS REGISTER 2
0104 483 $DEF UCBSW_MS_XSR3 .BLKW 1 ;EXTENDED STATUS REGISTER 3
0106 484
0106 485 .IF DF TS_TRACE
0106 486
0106 487 $DEF UCBSW_TRACESTS .BLKW 1 ;Status of trace.
0106 488 $DEF UCBSL_TRACEBEG .BLKL 1 ;Pointer to beginning of trace ring.
0106 489 $DEF UCBSL_TRACEPTR .BLKL 1 ;Pointer to next available slot.
0106 490 $DEF UCBSL_TRACEND .BLKL 1 ;Pointer to beyond trace ring.
0106 491
0106 492 TRACE_V_ACTIVE=0
0106 493 TRACE_M_ACTIVE=1
0106 494
0106 495 .ENDC
00000106 0106 496 UCBSK_MS_LENGTH=
0106 497 $DEFEND UCB
```



```
0000 499 .SBTTL DRIVER TABLES
0000 500
0000 501
0000 502
0000 503
0000 504
0000 505
0000 506
0000 507
0000 508
0000 509
0038 510
0038 511
003F 512
0043 513
0043 514
0043 515
0043 516
0043 517
0043 518
0043 519
0043 520
0043 521
004A 522
004A 523
0051 524
0055 525
0059 526
0060 527
0065 528
006A 529
006A 530
006E 531
0072 532
0076 533
0076 534
007B 535
0080 536
0085 537
00000001 0000 538
0000 539
0000 540
0000 541
0000 542
0000 543
0000 544
0000 545
0000 546
0000 547
0000 548
0000 549
0000 550
0000 551
0038 552
0038 553
0038 554
0038 555

: DRIVER PROLOGUE TABLE

DPTAB - ;DEFINE DRIVER PROLOGUE TABLE
END=TS END,- ;END OF DRIVER
ADAPTER=UBA,- ;UNIBUS ADAPTER
UCBSIZE=UCBSK_MS_LENGTH,-
NAME=TSRIVER ;DRIVER NAME
DPT_STORE INIT ;CONTROL BLOCK INIT VALUE
DPT_STORE DDB,DDBSL_ACPD,L,<^A\MTA\> ;DEFAULT ACP NAME
DPT_STORE UCB,UCBSB_FIPL,B,8 ;FORK IPL
DPT_STORE UCB,UCBSL_DEVCHAR,L,- ;DEVICE CHARACTERISTICS
<DEVSM_FOD- ;FILES ORIENTED
DEVSM_DIR- ;DIRECTORY STRUCTURED
DEVSM_AVL- ;AVAILABLE
DEVSM_ELG- ;ERROR LOGGING ENABLED
DEVSM_IDV- ;INPUT DEVICE
DEVSM_ODV- ;OUTPUT DEVICE
DEVSM_SDI- ;SINGLE DIRECTORY DEVICE
DEVSM_SQD> ;SEQUENTIAL DEVICE
DPT_STORE UCB,UCBSL_DEVCHAR2,L,- ;DEVICE CHARACTERISTICS
<DEVSM_NNM> ;PREFIX NAME WITH 'nodes'
DPT_STORE UCB,UCBSB_DEVCLASS,B,DC$ TAPE ;DEVICE CLASS
DPT_STORE UCB,UCBSB_DEVTYPE,B,DTS TS11 ;DEVICE TYPE
DPT_STORE UCB,UCBSL_MEDIA_ID,L,MEDIA_ID TS11 ;DEVICE MEDIA ID
DPT_STORE UCB,UCBSW_DEVBUFSIZ,W,2048 ;DEFAULT BUFFER SIZE
DPT_STORE UCB,UCBSL_DEVDEPEND,W,<^X4C0> ;DEFAULT TAPE PARAMETERS
; FORMAT=NORMAL11,DENSITY=1600BPI
DPT_STORE UCB,UCBSB_DIPL,B,21 ;DEVICE IPL
DPT_STORE UCB,UCBSB_ERTCNT,B,16 ;ERROR RETRY COUNT
DPT_STORE UCB,UCBSB_ERTMAX,B,16 ;MAX ERROR RETRY COUNT
DPT_STORE REINIT ;CONTROL BLOCK RE-INIT VALUES
DPT_STORE CRB,CRBSL_INTD+4,D,TS$INT ;INTERRUPT SERVICE ROUTINE ADDR.
DPT_STORE CRB,CRBSL_INTD+VEC$L UNITINIT,D,TS INIT ;UNIT INIT
DPT_STORE DDB,DDBSL_DDT,D,MS$DDT ;DDT ADDRESS
DPT_STORE END
.MDELETE DPT_STORE

: DRIVER DISPATCH TABLE

DDTAB MS,- ;(MS=GENERIC NAME)DRIVER DISPATCH TABLE
TS_STARTIO,- ;START I/O OPERATION
0,- ;UNSOLICITED INTERRUPT
TS_FUNCABLE,- ;FUNCTION DECISION TABLE
+IOC$CANCELIO,- ;CANCEL I/O ENTRY POINT(STANDARD)
TS_REGDUMP,- ;REGISTER DUMP ROUTINE
<8T4+<1+23>*4>,- ;DIAG. BUFFER SIZE
<<1+23>*4+EMBSL_DV_REGSAB> ;ERROR BUFFER SIZE

: HARDWARE COMMAND TABLE - MODES/CODES
```

| | | | | |
|------|-----|--------|-------|--------|
| 0038 | 556 | | | |
| 0038 | 557 | HCTAB: | | |
| 0038 | 558 | | GENHC | HC_NOP |
| 003A | 559 | | GENHC | HC_UNL |
| 003C | 560 | | GENHC | HC_STF |
| 003E | 561 | | GENHC | HC_RWD |
| 0040 | 562 | | GENHC | HC_DRI |
| 0042 | 563 | | GENHC | HC_STR |
| 0044 | 564 | | GENHC | HC_ERS |
| 0046 | 565 | | GENHC | HC_SRR |
| 0048 | 566 | | GENHC | HC_PAK |
| 004A | 567 | | GENHC | HC_SRF |
| 004C | 568 | | GENHC | HC_WCK |
| 004E | 569 | | GENHC | HC_WRD |
| 0050 | 570 | | GENHC | HC_RDN |
| 0052 | 571 | | GENHC | HC_WKR |
| 0054 | 572 | | GENHC | HC_WRD |
| 0056 | 573 | | GENHC | HC_RDP |
| 0058 | 574 | | GENHC | HC_RRN |
| 005A | 575 | | GENHC | HC_RRP |
| 005C | 576 | | GENHC | HC_WDR |
| 005E | 577 | | GENHC | HC_RPS |
| 0060 | 578 | | GENHC | HC_SCH |
| 0062 | 579 | | GENHC | HC_GST |
| 0064 | 580 | | GENHC | HC_WTM |
| 0066 | 581 | | GENHC | HC_WTR |
| 0068 | 582 | | GENHC | HC_CLN |
| 006A | 583 | | GENHC | HC_BRL |
| 006C | 584 | | GENHC | HC_WSM |
| 006E | 585 | | GENHC | HC_WRC |
| 0070 | 586 | | | |
| 0070 | 587 | | | |

| | | | | |
|--|--|--|--|-------------------------------------|
| | | | | ;SIMULATED NOP |
| | | | | ;REWIND & UNLOAD |
| | | | | ;SKIP TAPE MARK FORWARD(SPACE FILE) |
| | | | | ;REWIND |
| | | | | ;DRIVE INITIALIZE(DRIVE CLEAR) |
| | | | | ;SKIP TAPE MARK REVERSE |
| | | | | ;ERASE |
| | | | | ;SKIP RECORD REVERSE |
| | | | | ;SIMULATED PACK ACKNOWLEDGE |
| | | | | ;SKIP RECORD FORWARD |
| | | | | ;SIMULATED WRITECHECK |
| | | | | ;WRITE DATA(WRITEPBLK) |
| | | | | ;READ DATA NEXT(READPBLK) |
| | | | | ;SIMULATED WRITECHECK REV. |
| | | | | ;WRITE DATA(NO WRITEPBLK REV.) |
| | | | | ;READ DATA PREVIOUS |
| | | | | ;REREAD DATA NEXT |
| | | | | ;REREAD DATA PREVIOUS |
| | | | | ;WRITE DATA RETRY |
| | | | | ;SIMULATED READ PRESET |
| | | | | ;SIMULATED SET CHARACTERISTIC |
| | | | | ;GET STATUS IMMEDIATE |
| | | | | ;WRITE TAPE MARK |
| | | | | ;WRITE TAPE MARK RETRY |
| | | | | ;CLEAN |
| | | | | ;MESSAGE BUFFER RELEASE |
| | | | | ;WRITE SUBSYSTEM MEMORY |
| | | | | ;WRITE CHARACTERISTIC |


```
0070 589 ;+
0070 590
0070 591 : TS11/TS04 FUNCTION DECISION TABLE
0070 592 :-
0070 593
0070 594 TS_FUNCTABLE:
0070 595 FUNCTAB
0070 596 <NOP,-
0070 597 UNLOAD,-
0070 598 SPACERECORD,-
0070 599 RECAL,-
0070 600 DRVCLR,-
0070 601 READPRESET,-
0070 602 PACKACK,-
0070 603 ERASETAPE,-
0070 604 SENSECHAR,-
0070 605 SETCHAR,-
0070 606 SPACEFILE,-
0070 607 WRITECHECK,-
0070 608 WRITEPBLK,-
0070 609 WRITERET,-
0070 610 READPBLK,-
0070 611 REREADN,-
0070 612 REREADP,-
0070 613 AVAILABLE,-
0070 614 WRITEMARK,-
0070 615 WRTTMKR,-
0070 616 CLEAN,-
0070 617 READLBLK,-
0070 618 WRITELBLK,-
0070 619 SENSEMODE,-
0070 620 SETMODE,-
0070 621 REWIND,-
0070 622 REWINDOFF,-
0070 623 SKIPRECORD,-
0070 624 SKIPFILE,-
0070 625 WRITEOF,-
0070 626 READVBLK,-
0070 627 WRITEVBLK,-
0070 628 ACCESS,-
0070 629 ACPCONTROL,-
0070 630 CREATE,-
0070 631 DEACCESS,-
0070 632 DELETE,-
0070 633 MODIFY,-
0070 634 MOUNT>
0078 635 FUNCTAB,-
0078 636 <NOP,-
0078 637 UNLOAD,-
0078 638 SPACERECORD,-
0078 639 RECAL,-
0078 640 DRVCLR,-
0078 641 READPRESET,-
0078 642 PACKACK,-
0078 643 ERASETAPE,-
0078 644 SENSECHAR,-
0078 645 SETCHAR,-

;FUNCTION DECISION TABLE
;LEGAL FUNCTIONS
;NO OPERATION
;UNLOAD VOLUME
;SPACE RECORDS
;RECALIBRATE (REWIND)
;DRIVER CLEAR
;READ IN PRESET
;PACK ACKNOWLEDGE
;ERASE TAPE
;SENSE TAPE CHARACTERISTICS
;SET CHARACTERISTICS
;SPACE FILE
;WRITE CHECK FORWARD
;WRITE PHYSICAL BLOCK
;**NEW**WRITE PHYSICAL BLOCK RETRY
;READ PHYSICAL BLOCK
;**NEW**REREAD NEXT
;**NEW**REREAD PREVIOUS
;AVAILABLE (REWIND/NOWAIT CLEAR VALID)
;WRITE TAPE MARK
;**NEW**WRITE TAPE MARK RETRY
;**NEW**CLEAN TAPE
;READ LOGICAL BLOCK
;WRITE LOGICAL BLOCK
;SENSE TAPE MODE
;SET MODE
;REWIND
;REWIND AND SET OFFLINE
;SKIP RECORDS
;SKIP FILES
;WRITE END OF FILE
;READ VIRTUAL BLOCK
;WRITE VIRTUAL BLOCK
;ACCESS FILE AND/OR FIND DIRECTORY
;ACP CONNTROL FUNCTION
;CREATE FILE AND/OR CREATE DIRECTORY
;DEACCESS FILE
;DELETE FILE AND/OR DIRECTORY ENTRY
;MODIFY FILE ATTRIBUTES
;MOUNT VOLUME
;BUFFERED I/O FUNCTIONS
;NO OPERATION
;UNLOAD VOLUME
;SPACE RECORDS
;RECALIBRATE (REWIND)
;DRIVE CLEAR
;READ PRESET
;PACK ACKNOWLEDGE
;ERASE TAPE
;SENSE CHARACTERISTICS
;SET CHARACTERISTICS
```

| | | | |
|------|-----|-------------------------------------|--|
| 0078 | 646 | SPACEFILE,- | :SPACE FILES |
| 0078 | 647 | WRITEMARK,- | :WRITE TAPE MARK |
| 0078 | 648 | WRTTMKR,- | :**NEW**WRITE TAPE MARK RETRY |
| 0078 | 649 | CLEAN,- | :**NEW**CLEAN TAPE |
| 0078 | 650 | SENSEMODE,- | :SENSE MODE |
| 0078 | 651 | SETMODE,- | :SET MODE |
| 0078 | 652 | REWIND,- | :REWIND |
| 0078 | 653 | REWINDOFF,- | :REWIND AND UNLOAD |
| 0078 | 654 | SKIPRECORD,- | :SKIP RECORDS |
| 0078 | 655 | SKIPFILE,- | :SKIP FILES |
| 0078 | 656 | WRITEOF,- | :WRITE END OF FILE |
| 0078 | 657 | ACCESS,- | :ACCESS FILE AND/OR FIND DIRECTORY ENTRY |
| 0078 | 658 | ACPCONTROL,- | :ACP CONTROL FUNCTION |
| 0078 | 659 | CREATE,- | :CREATE FILE AND/OR CREATE DIRECTORY ENTRY |
| 0078 | 660 | DEACCESS,- | :DEACCESS FILE |
| 0078 | 661 | DELETE,- | :DELETE FILE AND/OR DIRECTORY ENTRY |
| 0078 | 662 | MODIFY,- | :MODIFY FILE ATTRIBUTES |
| 0078 | 663 | MOUNT> | :MOUNT VOLUME |
| 0080 | 664 | FUNCTAB +ACPSREADBLK,- | :READ FUNCTIONS |
| 0080 | 665 | <READLBLK,- | :READ LOGICAL BLOCK FORWARD |
| 0080 | 666 | READPBLK,- | :READ PHYSICAL BLOCK FORWARD |
| 0080 | 667 | REREADN,- | :*NEW*REREAD NEXT |
| 0080 | 668 | REREADP,- | :*NEW*REREAD PREVIOUS |
| 0080 | 669 | READVBLK> | :READ VIRTUAL BLOCK |
| 008C | 670 | FUNCTAB +ACPSWRITEBLK,- | :WRITE FUNCTIONS |
| 008C | 671 | <WRITECHECK,- | :WRITE CHECK FORWARD |
| 008C | 672 | WRITELBLK,- | :WRITE LOGICAL BLOCK |
| 008C | 673 | WRITEPBLK,- | :WRITE PHYSICAL BLOCK |
| 008C | 674 | WRITERET,- | :*NEW*WRITE RETRY |
| 008C | 675 | WRITEVBLK> | :WRITE VIRTUAL BLOCK |
| 0098 | 676 | FUNCTAB +ACPSACCESS,<ACCESS,CREATE> | :ACCESS AND CREATE FILE OR DIRECTORY |
| 00A4 | 677 | FUNCTAB +ACPSDEACCESS,<DEACCESS> | :DEACCESS FILE |
| 00B0 | 678 | FUNCTAB +ACPSMODIFY,- | : |
| 00B0 | 679 | <ACPCONTROL,- | :ACP CONTROL FUNCTION |
| 00B0 | 680 | DELETE,- | :DELETE FILE OR DIRECTORY ENTRY |
| 00B0 | 681 | MODIFY> | :MODIFY FILE ATTRIBUTES |
| 00BC | 682 | FUNCTAB +ACPSMOUNT,<MOUNT> | :MOUNT VOLUME |
| 00C8 | 683 | FUNCTAB +MTSCHECK ACCESS,- | :MAGTAPE CHECK ACCESS FUNCITONS |
| 00C8 | 684 | <ERASETAPE,- | :ERASE TAPE |
| 00C8 | 685 | CLEAN,- | :**NEW**CLEAN TAPE |
| 00C8 | 686 | WRITEMARK,- | :WRITE TAPE MARK |
| 00C8 | 687 | WRTTMKR,- | :*NEW*WRITE TAPE MARK RETRY |
| 00C8 | 688 | WRITEOF> | :WRITE END OF FILE |
| 00D4 | 689 | FUNCTAB +EXESZEROPARM,- | :ZERO PARAMETER FUNCTIONS |
| 00D4 | 690 | <NOP,- | :NO OPERATION |
| 00D4 | 691 | UNLOAD,- | :UNLOAD VOLUME |
| 00D4 | 692 | RECAL,- | :RECALIBRATE (REWIND) |
| 00D4 | 693 | REWIND,- | :REWIND |
| 00D4 | 694 | REWINDOFF,- | :REWIND AND SET OFFLINE |
| 00D4 | 695 | DRVCLR,- | :DRIVE CLEAR |
| 00D4 | 696 | READPRESET,- | :READ IN PRESET |
| 00D4 | 697 | PACKACK,- | :PACK ACKNOWLEDGE |
| 00D4 | 698 | ERASETAPE,- | :ERASE TAPE |
| 00D4 | 699 | CLEAN,- | :**NEW**CLEAN TAPE |
| 00D4 | 700 | SENSECHAR,- | :SENSE TAPE CHARACTERISTICS |
| 00D4 | 701 | SENSEMODE,- | :SENSE TAPE MODE |
| 00D4 | 702 | AVAILABLE,- | :AVAILABLE (REWIND/NOWAIT CLEAR VALID) |

| | | | | |
|------|-----|---------|----------------|-----------------------------|
| 00D4 | 703 | | WRITEMARK,- | :WRITE TAPE MARK |
| 00D4 | 704 | | WRITMKR,- | :*NEW*WRITE TAPE MARK RETRY |
| 00D4 | 705 | | WRITEOF> | :WRITE END OF FILE |
| 00E0 | 706 | FUNCTAB | +EXESONEPARM,- | :ONE PARAMETER FUNCTIONS |
| 00E0 | 707 | | <SPACERECORD,- | :SPACE RECORDS |
| 00E0 | 708 | | SPACEFILE,- | :SPACE FILES |
| 00E0 | 709 | | SKIPRECORD,- | :SKIP RECORDS |
| 00E0 | 710 | | SKIPFILE> | :SKIP FILES |
| 00EC | 711 | FUNCTAB | +EXESSETMODE,- | :SET TAPE CHARACTERISTICS |
| 00EC | 712 | | <SETCHAR,- | : |
| 00EC | 713 | | SETMODE> | : |
| 00F8 | 714 | | | : |

```
00F8 716      .IF      DF      TS TRACE
00F8 717      :SBTTL  +      TRACE_IRP and TRACE_STATUS
00F8 718
00F8 719      : Routines to record IRP and I/O status contents in the trace table.
00F8 720      : Trace table entries are 96 bytes long so that they line up nicely in
00F8 721      : a dump.
00F8 722
00F8 723      TRACE_IRP
00F8 724
00F8 725      Inputs:
00F8 726      :      R3 => IRP
00F8 727      :      R5 => UCB
00F8 728
00F8 729      TRACE_IRP:
00F8 730
00F8 731      BBC      #TRACE_V_ACTIVE,-      : If trace table not intialized,
00F8 732      UCB$W_TRACESTS(R5),20$      : branch around.
00F8 733      MOVQ     R0,-(SP)      : Save R0 and R1.
00F8 734      MOVL     R3,R0      : R0 => IRP to trace.
00F8 735      CMPL     UCB$L_TRACEEND(R5),-      : See if we should circle back to start
00F8 736      UCB$L_TRACEPTR(R5)      : of trace table.
00F8 737      BGTR     10$      : GTR implies NO.
00F8 738      MOVL     UCB$L_TRACEBEG(R5),-      : TRACE_PTR => base of trace table.
00F8 739      UCB$L_TRACEPTR(R5)
00F8 740 10$:
00F8 741      MOVL     UCB$L_TRACEPTR(R5),R1      : R1 => area in trace table to use.
00F8 742
00F8 743      MOVQ     (R0)+,(R1)+      : Twelve quad words are 96 bytes.
00F8 744      MOVQ     (R0)+,(R1)+
00F8 745      MOVQ     (R0)+,(R1)+
00F8 746      MOVQ     (R0)+,(R1)+
00F8 747      MOVQ     (R0)+,(R1)+
00F8 748      MOVQ     (R0)+,(R1)+
00F8 749      MOVQ     (R0)+,(R1)+
00F8 750      MOVQ     (R0)+,(R1)+
00F8 751      MOVQ     (R0)+,(R1)+
00F8 752      MOVQ     (R0)+,(R1)+
00F8 753      MOVQ     (R0)+,(R1)+
00F8 754      MOVQ     (R0)+,(R1)+
00F8 755
00F8 756      MOVL     UCB$L_TRACEPTR(R5),R1      : R1 => area in trace table to use.
00F8 757      MOVL     R3,(R1)      : Trace entry => IRP.
00F8 758      MNEGL     #1,4(R1)      : Init flag field.
00F8 759      MNEGL     #1,IRP$L_ARB(R1)      : Init field for I/O Status #1.
00F8 760      MNEGL     #1,IRP$L_ARB+4(R1)      : Init field for I/O Status #2.
00F8 761      MOVQ     (SP)+,R0      : Restore R0 and R1.
00F8 762 20$:
00F8 763      RSB
00F8 764
00F8 765      : TRACE_STATUS
00F8 766
00F8 767      Inputs:
00F8 768
00F8 769      :      R0 = I/O status value #1.
00F8 770      :      R5 => UCB
00F8 771      :      UCB$L_DEVDEPEND = I/O status #2.
00F8 772
```

```

00F8 773 TRACE_STATUS:
00F8 774
00F8 775      BBC      #TRACE_V_ACTIVE,-      ; If Trace table not active, branch.
00F8 776      UCB$W_TRACESTS(R5),30$
00F8 777      PUSHL   R2                      ; Save register.
00F8 778      MOVL    UCB$L_TRACEPTR(R5),R2   ; R2 => area in trace table to use.
00F8 779
00F8 780      MOVL    R0,IRP$L_ARB(R2)         ; Save I/O status.
00F8 781      MOVL    UCB$L_DEVDEPEND(R5),-   ;
00F8 782      IRP$L_ARB+4(R2)
00F8 783      POPL    R2                      ; Restore register.
00F8 784      ADDL    #96,UCB$L_TRACEPTR(R5)   ; Point to next entry.
00F8 785 30$:
00F8 786      RSB
00F8 787
00F8 788      .ENDC
  
```



```
00F8 790 .SBTTL UNIT INITIALIZATION ROUTINE
00F8 791 *
00F8 792 THIS ROUTINE IS CALLED WHEN THE DRIVER IS LOADED OR ON POWERFAIL
00F8 793 RECOVERY.
00F8 794
00F8 795 CALLING SEQUENCE:
00F8 796 JSB TS_INIT
00F8 797
00F8 798 INPUT:
00F8 799 R5 = UCB ADDRESS
00F8 800 R4 = EQUIVALENT CSR FOR TS11
00F8 801
00F8 802 OUTPUT:
00F8 803
00F8 804
00F8 805 TS_INIT:
10  A8 00F8 806 B1SW #UCBSM_ONLINE,- ; Always mark TS11 as online since
64 A5 00FA 807 UCBSW_STS(R5) ; interrupts are not normally enabled
00FC 808 ; we have no method to set it on
05 11 00FC 809 ; dynamically.
00FE 810 BRB 50$ ; Go to allocate buffer and load registers
10  AA 00FE 811 15$: B1CW #UCBSM_ONLINE,- ; Only reason for marking TS11 offline
64 A5 0100 812 UCBSW_STS(R5) ; is lack of pool space for PACKET.
0102 813 20$:
05 0102 814 RSB ;RETURN
0103 815 50$:
0103 816 .IF DF TS TRACE
0103 817 BBS #TRACE_V_ACTIVE,- ; If trace table already intialized,
0103 818 UCBSW_TRACESTS(R5),52$ ; branch around.
0103 819 MOVL #50*96+16,R1 ; Allocate trace table for 50 entries.
0103 820 PUSHL G^EXESGL_NONPAGED ; Save nonpaged IPL.
0103 821 MFPR #PRS_IPL,G^EXESGL_NONPAGED ; Use current IPL.
0103 822 JSB G^EXESALONONPAGED ; Get from non-paged memory.
0103 823 POPL G^EXESGL_NONPAGED ; Restore nonpaged IPL.
0103 824 BLBC R0,52$ ; Space not available, branch around.
0103 825
0103 826 CLRQ (R2)+ ; Initialize trace table header for SDA.
0103 827 MOVW R1,(R2)+ ; Save size.
0103 828 MOVW #DYN$C_SCS,(R2)+ ; Type.
0103 829 CLRL (R2)+ ; Round header upto 16 byte boundary.
0103 830 MOVL R2,UCBSL_TRACEBEG(R5) ; Save pointer to base of trace tabl
0103 831 MOVL R2,UCBSL_TRACEPTR(R5) ; Pointer to next area to use.
0103 832 ADDL3 #50*96,R2,- ; Pointer to beyond end of trace
0103 833 UCBSL_TRACEEND(R5) ; table.
0103 834 B1SW #TRACE_M_ACTIVE,- ; Indicate Trace table initied.
0103 835 UCBSW_TRACESTS(R5)
0103 836
0103 837 52$:
0103 838 .ENDC
51 24 A5 D0 0103 839 MOVL UCBSL_CRB(R5),R1 ;GET POINTER TO CRB
34 A1 D0 0107 840 MOVL CRBSL_INTD+VECSW_MAPREG(R1),-
00E8 C5 D0 010A 841 UCBSL_MS_TMP2(R5) ;SAVE CURRENT UBA MAP CONTEXT.
50 2C A1 D0 010D 842 MOVL CRBSL_INTD+VECSL_IDB(R1),R0 ;GET POINTER TO IDB
04 A0 55 D0 0111 843 MOVL R5,IDBSL_OWNER(R0) ;MAKE UCB OWNER OF IDB
51 20 D0 0115 844 MOVL #32,R1 ;SIZE OF WORK BUFFER FOR TS11(=32.)
52 00B6 C5 D0 0118 845 MOVL UCBSL_MS_TSPT1(R5),R2 ;IF THE BUFFER HAS ALREADY BEEN ALLOCATED
25 12 011D 846 BNEQ 60$ ;BRANCH AROUND ELSE ALLOCATE THE BUFFER
```

```
011F 847
011F 848 : DRIVER LOAD
011F 849 :
011F 850 :
011F 851 :
011F 852 55$:
011F 853 PUSHL G^EXESGL_NONPAGED :SAVE NONPAGED IPL
00000000'GF DD 011F 854 MFPR #PR$ IPL,G^EXESGL_NONPAGED :USE CURRENT IPL
00000000'GF 12 DB 0125 854 JSB G^EXESGL_NONPAGED :GET FROM NON-PAGED MEMORY
00000000'GF 16 012C 855 POPL G^EXESGL_NONPAGED :RESTORE NONPAGED IPL
00000000'GF 8ED0 0132 856 BLBS R0,57$ : Space available, branch aroundd.
03 50 EB 0139 857 BRW 15$ : Branch on allocation failure.
FFBF 31 013C 858
013F 859 57$:
013F 860 :YES, R1=SIZE OF ALLOCATED BLOCK
013F 861 : R2 HAS ADDR. OF THE BLOCK
00B6 C5 52 DO 013F 862 MOVL R2,UCBSL_MS_TSPT1(R5) :STORE ADDR. IN UCB
0144 863 60$:
0144 864 ASSUME UCBSW_BOFF EQ UCBSL_SVAPTE+4
0144 865 ASSUME UCBSW_BCNT EQ UCBSW_BOFF+2
78 A5 7D 0144 866 MOVQ UCBSL_SVAPTE(R5),-
00E0 C5 0147 867 UCBSQ_MS_TMP1(R5) :SAVE UCBSL_SVAPTE, W_BCNT, W_BOFF.
014A 868
7E A5 51 B0 014A 869 MOVW R1,UCBSW_BCNT(R5) :LOAD BYTE COUNT INTO UCB
7C A5 52 FE00 8F AB 014E 870 BICW3 #^XFE00,R2,UCBSW_BOFF(R5) :LOAD BYTE OFFSET IN UCB
52 52 15 09 EF 0155 871 EXTZV S^#VASV_VPN,S^#VASS_VPN,R2,R2 :GET VIRTUAL PAGE #
50 00000000'GF DO 015A 872 MOVL G^MMGSG[ SPBASE,R0 :GET ADDR. OF SYS. PAGE TABLE
78 A5 6042 DE 0161 873 MOVAL (R0)[R2],UCBSL_SVAPTE(R5) :STORE SVA OF PTE FOR WORK BUFFER
0166 874 :LOADED BCNT,BOFF,&SVAPTE FOR WORK BUFFER
0166 875 :DIRECT DATA PATH IS USED FOR COMMUNICATION
51 24 A5 DO 0166 876 MOVL UCBSL_CRB(R5),R1 : R1 => CRB
34 A1 00D8 C5 DO 016A 877 MOVL UCBSL_MS_OMPR(R5),CRBSL_INTD+VECSW_MAPREG(R1) :IF NEQ USE OLD MAP RE
13 12 0170 878 BNEQ 80$ :GOTO LOAD MAP REGISTER
37 A1 94 0172 879 70$:
0175 880 CLRB CRBSL_INTD+VECSB_DATAPATH(R1) :INSURE DIRECT DATA PATH(=0)
017B 881 REQMPR :ALLOCATE MAP REGISTER(S) TO MAP UNIBUS
51 24 A5 DO 017B 882 MOVL UCBSL_CRB(R5),R1 :GET POINTER TO CRB
00D8 C5 34 A1 DO 017F 883 MOVL CRBSL_INTD+VECSW_MAPREG(R1),UCBSL_MS_OMPR(R5) :SAVE OLD MAP REGISTER
0185 884 80$:
78 A5 7D 0185 885 MOVQ UCBSL_SVAPTE(R5),- : Save message buffer parameters to
00EC C5 0188 886 UCBSQ_MS_BUFVAPTE(R5) : facilitate later remapping.
0188 887 :TO SBI ADDRESSES
0188 888 : THE NO. OF MAP REGISTER AND STARTING
0188 889 : MAP REG. NO. ARE STORED IN CRB
0188 890 :LOAD MAP REG. TO BE USED
LOADUBA
0191 891 :
0191 892 : CALCULATE UNIBUS ADDR. FOR COMMAND PACKET, STORE IT IN UCB
0191 893 :
50 7C A5 3C 0191 894 MOVZWL UCBSW_BOFF(R5),R0 :GET BYTE OFFSET
00EC C5 7D 0195 895 MOVQ UCBSQ_MS_TMP1(R5),-
78 A5 0199 896 UCBSL_SVAPTE(R5) :RESTORE SVAPTE, BOFF, BCNT
019B 897
51 24 A5 DO 019B 898 MOVL UCBSL_CRB(R5),R1 :GET CRB
50 09 09 34 A1 FO 019F 899 INSV CRBSL_INTD+VECSW_MAPREG(R1),#9,#9,R0 : HIGH 9 BITS
00BA C5 50 DO 01A5 900 MOVL R0,UCBSL_MS_TSPT2(R5) :STORE IN UCB
00E8 C5 DO 01AA 901 MOVL UCBSL_MS_TMP2(R5),-
34 A1 01AE 902 CRBSL_INTD+VECSW_MAPREG(R1) :RESTORE UNIBUS MAPPING CONTEXT
51 D4 01B0 903 CLRL R1 :CLEAR R1
```

| | | | | | | | | | |
|----|------|------|----|------|------|-----|------|-------------------------------------|--|
| 50 | 50 | FE | BF | 78 | 01B2 | 904 | ASHL | #-2,R0,R0 | :MODULO 4,SHIFT OUT 2 0'S |
| 51 | 0E | 02 | 50 | F0 | 01B7 | 905 | INSV | R0,#2,#14,R1 | :INSERT B2-B15 |
| 50 | 50 | F2 | BF | 78 | 01BC | 906 | ASHL | #-14,R0,R0 | :SHIFT OUT B2-B15 |
| 51 | 02 | 00 | 50 | F0 | 01C1 | 907 | INSV | R0,#0,#2,R1 | :INSERT B16-B17 |
| | 00BE | C5 | 51 | B0 | 01C6 | 908 | MOVW | R1,UCBSW_MS_TSPT3(R5) | :STORE COMMAND PTR IN UCB |
| | | | | | 01CB | 909 | | | |
| | | | | | 01CB | 910 | | | |
| | | | | | 01CB | 911 | | | |
| | | | | | 01CB | 912 | | | |
| | | | | | 01CB | 913 | | | |
| 50 | 00B6 | C5 | D0 | 01CB | 913 | | MOVL | UCBSL_MS_TSPT1(R5),R0 | :COMMAND PACKET ADDR. IN R0 |
| 60 | C0B4 | BF | B0 | 01D0 | 914 | | MOVW | #<HC ORCTMS CPHD M_ACK>,MS_CPHD(R0) | :GET COMMAND PACKET HEADER |
| 02 | A0 | 00BA | C5 | D0 | 01D5 | 915 | MOVL | UCBSL_MS_TSPT2(R5),MS_BACT(R0) | :STORE CHAR. BUFFER ADDR. |
| | 02 | A0 | 08 | C0 | 01DB | 916 | ADDL | #8,MS_BACT(R0) | :POINT TO CHAR. BUFFER NOW |
| | 06 | A0 | 08 | B0 | 01DF | 917 | MOVW | #8,MS_CNT(R0) | :STORE BYTE COUNT FOR CHAR. DATA |
| 08 | A0 | 00BA | C5 | D0 | 01E3 | 918 | MOVL | UCBSL_MS_TSPT2(R5),MS_MBAO(R0) | :STORE MESSAGE BUFFER ADDR. |
| | 08 | A0 | 10 | C0 | 01E9 | 919 | ADDL | #16,MS_MBAO(R0) | :AS CHAR. DATA |
| | 0C | A0 | 0E | B0 | 01ED | 920 | MOVW | #14,MS_LNTH(R0) | :LENGTH OF CHAR. DATA=14. |
| | | 0E | A0 | B4 | 01F1 | 921 | CLRW | MS_CHWD(R0) | :ZERO CHARACTERISTIC WORD |
| | | | | | 01F4 | 922 | | | :**=>NO MESSAGE BUFFER RELEASE INTERRUPT |
| | | | | | 01F4 | 923 | | | :** NO ATTENTION INTERRUPT, AND NO |
| | | | | | 01F4 | 924 | | | :** SKIP TAPE MARKS STOP |
| | | | | | 01F4 | 925 | | | |
| | | | | | 01F4 | 926 | | | |
| | | | | | 01F4 | 927 | | | |
| | | | | | 01F4 | 928 | | | |
| 64 | 00BE | C5 | B0 | 01F4 | 928 | | MOVW | UCBSW_MS_TSPT3(R5),(R4) | :LOAD INTO TSDB |
| 68 | A5 | 0400 | BF | AB | 01F9 | 929 | BISW | #UCBSM_MS_LBA,UCBSW_DEVST(S(R5) | :MARK LOADING MESSAGE BUFFER |
| | | | | | 01FF | 930 | | | :ADDR. INTO TS11. |
| | | | 05 | 01FF | 931 | | RSB | | :RETURN |
| | | | | | 0200 | 932 | | | |
| | | | | | 0200 | 933 | | | |


```
0200 935 .SBTTL TEST_NBA (NEED BUFFER ADDRESS)
0200 936
0200 937 : TEST_NBA - Subroutine called from STARTIO to determine if the TS11 has
0200 938 : a valid message buffer. If YES, then we merely return. If NOT, we
0200 939 : re-establish the message buffer obtained at SYSTEM INIT time.
0200 940
0200 941 This routine assumes that the following UCB fields were initialized
0200 942 : at UNIT INIT time:
0200 943
0200 944 UCB$Q_MS_BUF$VAPTE
0200 945 UCB$Q_MS_OMPR
0200 946
0200 947 INPUTS:
0200 948 R5 => UCB
0200 949
0200 950 OUTPUTS:
0200 951 Message buffer established in TS11.
0200 952
0200 953
0200 954 TEST_NBA:
009C C5 8ED0 0200 955 POPL UCB$Q_DPC(R5) ; Pop return off stack in case.
0400 8F AA 0205 956 BICW #UCB$Q_MS_LBA,- ; This bit maybe left on from INIT if
68 A5 0209 957 UCB$Q_DEVSTS(R5) ; setting of switches inside drive so
020B 958 ; dictate. We clear it here because
020B 959 ; this is a convenient place.
020B 960
51 24 A5 D0 020B 961 MOVL UCB$Q_CRB(R5),R1 ; R1 => CRB
020F 962 ASSUME IDB$Q_CSR EQ 0
54 2C B1 D0 020F 963 MOVL @CRB$Q_INTD+VEC$Q_IDB(R1),R4 ; R4 => CSR.
50 02 A4 B0 0213 964 MOVW 2(R4),R0 ; R0 contains TSSR register.
03 50 07 E0 0217 965 BBS #MS_TSSR_V_SSR,R0,10$ ; Branch to continue if TS11 ready.
009A 31 021B 966 BRW 60$ ; Branch to failure if NOT ready.
021E 967 10$:
07 50 0A E0 021E 968 BBS #MS_TSSR_V_NBA,R0,20$ ; Branch around if we NEED to re-
0222 969 ; establish message buffer address.
50 01 9A 0222 970 MOVZBL S^#SS$_NORMAL,R0 ; Else indicate success and
009C D5 17 0225 971 JMP @UCB$Q_DPC(R5) ; return to caller.
0229 972 20$:
34 A1 D0 0229 973 MOVL CRB$Q_INTD+VEC$Q_MAPREG(R1),-
00E8 C5 022C 974 UCB$Q_MS_TMP2(R5) ;SAVE CURRENT UBA MAP CONTEXT.
00D8 C5 D0 022F 975 MOVL UCB$Q_MS_OMPR(R5),- ; Setup to map UNIBUS just in case
34 A1 0233 976 CRB$Q_INTD+VEC$Q_MAPREG(R1)
0235 977
0235 978 ASSUME UCB$Q_BOFF EQ UCB$Q_SVAPTE+4
0235 979 ASSUME UCB$Q_BCNT EQ UCB$Q_BOFF+2
78 A5 7D 0235 980 MOVQ UCB$Q_SVAPTE(R5),-
00E0 C5 0238 981 UCB$Q_MS_TMP1(R5) ;SAVE UCB$Q_SVAPTE, W_BCNT, W_BOFF.
00EC C5 7D 0238 982 MOVQ UCB$Q_MS_BUF$VAPTE(R5),- ; Restore parameters to remap message
78 A5 023F 983 UCB$Q_SVAPTE(R5) ; buffer in UNIBUS space.
0241 984
0241 985 LOADUBA ; Reload UNIBUS map registers for
0247 986 ; message buffer.
0247 987
0247 988
0247 989 : ISSUE WRITE CHARACTERISTIC COMMAND TO TELL MESSAGE BUFFER ADDR. TO TS11
0247 990 :
50 00B6 C5 D0 0247 991 MOVL UCB$Q_MS_TSPT1(R5),R0 ; R0 => command packet
```

```
COB4 8F B0 024C 992 MOVW #<HC WRC!MS_CPHD_M_ACK>,-
60 0250 993 MS_CPHD(R0) ; Move command (WRITE CHARACTERISTICS)
00BA C5 D0 0251 994 ; to 1ST word of command packet.
02 02 02 0251 995 ; Store UNIBUS address of packet in
A0 08 C0 0255 996 MS_BACT(R0) packet.
06 A0 08 B0 0257 997 ADDL #8,MS_BACT(R0) ; Update to point to CHARACTERISTICS
00BA C5 D0 0258 998 ; buffer beyond packet.
08 08 A0 025F 1000 MOVW #8,MS_CNT(R0) ; Store byte count for char. data
0C A0 10 C0 0263 1001 MOVL UCBSL_MS_TSPT2(R5),- ; Store UNIBUS address of PACKET
0E 0E A0 0265 1002 MS_MBAO(R0) ; into the CHARACTERISTICS data.
0E 0E B4 0269 1003 ADDL #16,MS_MBAO(R0) ; Message BUFF is 16 beyond packet.
0E 0E B4 0269 1004 MOVW #14,MS_LNTH(R0) ; LENGTH OF CHAR. DATA=14.
0E 0E B4 026D 1005 CLRW MS_CHWD(R0) ; ZERO CHARACTERISTIC WORD
0270 1006 ;**=>NO MESSAGE BUFFER RELEASE INTERRUPT
0270 1007 ;** NO ATTENTION INTERRUPT, AND NO
0270 1008 ;** SKIP TAPE MARKS STOP
0270 1009 DSBINT
17 64 A5 05 E0 0276 1010 BBS #UCBSV_POWER,UCBSW_STS(R5),30$
64 00BE C5 B0 027B 1011 MOVW UCBSW_MS_TSPT3(R5),(R4) ; LOAD INTO TSDB
0280 1012 WFIKPCB 40$,#2 ; Wait for interrupt.
028A 1013 IOFORK
09 11 0290 1014 BRB 50$ ; Branch around powerfail branch.
0292 1015 30$: ENBINT
0295 1016 40$: SETIPL UCBSB_FIPL(R5) ; Lower IPL in case of TIMEOUT.
1D 11 0299 1017 BRB 60$ ; Branch if we had POWERFAIL.
029B 1018
029B 1019 50$:
51 24 A5 D0 029B 1020 MOVL UCBSL_CRB(R5),R1 ; R1 => CRB.
00E8 C5 D0 029F 1021 MOVL UCBSL_MS_TMP2(R5),- ; Restore previous mapping context.
34 A1 02A3 1022 CRBSL_INTD+VECSW_MAPREG(R1)
00E0 C5 7D 02A5 1023 MOVQ UCBSQ_MS_TMP1(R5),- ; And also transfer parameters.
78 A5 02A9 1024 UCBSL_SVAPTE(R5)
07 00C2 C5 E0 02AB 1025 BBS #MS_TSSR_V_NBA,- ; Test if all that had any effect
50 01 9A 02AD 1026 UCBSW_MS_TSSR(R5),60$ ; by seeing if we still have NBA.
009C D5 17 02B1 1027 MOVZBL S^#SS$_NORMAL,R0 ; Else indicate success and
02B4 1028 JMP @UCBSL_DPC(R5) ; return to caller.
02B8 1029 60$:
50 00B4 8F 3C 02B8 1031 MOVZWL #SS$_DEVOFFLINE,R0 ; Terminate the I/O function
009C D5 17 02BD 1032 JMP @UCBSL_DPC(R5) ; by returning the OFFLINE status and
; return to caller.
```

```
02C1 1034 .SBTTL START I/O OPERATION
02C1 1035
02C1 1036 TS_STARTIO - START I/O OPERATION ON DEVICE
02C1 1037
02C1 1038 THIS ENTRY POINT IS ENTERED TO START AN I/O OPERATION ON TS11/TS04
02C1 1039
02C1 1040 INPUTS:
02C1 1041
02C1 1042 R3 = ADDRESS OF I/O PACKET.
02C1 1043 R5 = UCB ADDRESS OF DEVICE UNIT
02C1 1044
02C1 1045 OUTPUT:
02C1 1046
02C1 1047 FUNCTION DEPENDENT PARAMETERS ARE STORED INTO THE DEVICE UCB,
02C1 1048 ERROR RETRY COUNT IS RESET, AND THE FUNCTION IS EXECUTED. AT
02C1 1049 FUNCTION COMPLETION THE OPERATION IS TERMINATED THRU REQUEST COMPLETE.
02C1 1050
02C1 1051 :-
02C1 1052
02C1 1053 TS_STARTIO: ;START I/O OPERATION
02C1 1054 .IF DF TS_TRACE
02C1 1055 BSBW TRACE_IRP ; Trace this IRP.
02C1 1056 .ENDC
02C1 1057 BSBW TEST_NBA ; Assure that TS11 has valid MESSAGE
02C4 1058 ; BUFFER.
02C4 1059 BLBS R0,5$ ; LBS implies success. GOTO continue.
02C7 1060 BRW FCNEXT ; Else branch to terminate function.
02CA 1061 5$:
02CA 1062 MOVW UCB$B_ERTMAX(R5),UCB$B_ERTCNT(R5) ;INITIALIZE ERROR RETRY COUNT
02D1 1063 MOVW IRP$W_FUNC(R3),UCB$W_FUNC(R5) ;SAVE FUNCTION CODE & MODIFIER
02D7 1064 MOVL IRP$L_MEDIA(R3),R0 ;GET PARAMETER LONGWORD
02DB 1065
02DB 1066
02DB 1067 ; MOVE FUNCTION DEPENDENT PARAMETERS TO UCB
02DB 1068
02DB 1069
02DB 1070 EXTZV #IRP$V_FCODE,#IRP$S_FCODE,- ;EXTRACT I/O FUNCTION CODEE
02DE 1071 IRP$W_FUNC(R3),R1
02E1 1072 CMPL #IOS_SPACEFILE,R1 ;SPACE FILE FUNCTION?
02E4 1073 BEQL 10$ ;IF EQL YES
02E6 1074 CMPL #IOS_SPACERECORD,R1 ;SPACE RECORD FUNCTION?
02E9 1075 BEQL 20$ ;IF EQL YES
02EB 1076 CMPL #IOS_SETCHAR,R1 ;SET CHARACTERISTICS FUNCTION?
02EE 1077 BEQL 50$ ;IF EQL YES
02F0 1078 CMPL #IOS_AVAILABLE,R1 ;AVAILABLE function?
02F3 1079 BEQL 75$ ;IF EQL YES
02F5 1080 CMPL #IOS_READPBLK+1,R1 ;DISJOINT CODE?
02F8 1081 BGTRU 100$ ;IF GTRU NO
02FA 1082 R1,<- ;DISPATCH LOGICAL FUNCTIONS
02FA 1083 70$,- ;REWIND AND SET OFFLINE
02FA 1084 60$,- ;SET MODE
02FA 1085 80$,- ;REWIND
02FA 1086 10$,- ;SKIP FILE
02FA 1087 20$,- ;SKIP RECORD
02FA 1088 90$,- ;SENSE TAPE MODE
02FA 1089 90$,- ;WRITE EOF
02FA 1090 >.LIMIT=#IOS_REWINDOFF ;
```

FF3C 30
03 50 E8
04CB 31
0080 C5 0081 C5 90
009A C5 20 A3 B0
50 38 A3 D0
51 06 00 EF
51 20 A3
51 02 D1
51 2B 13
51 09 D1
51 32 13
51 1A D1
51 46 13
51 11 D1
51 5A 13
51 0D D1
6C 1A


```
51 06 A2 030C 1091 SUBW #IOS_READPRESET-10$_READPBLK-7,R1 ;CONVERT TO DENSE FUNCTION CODE
63 11 030F 1092 BRB 110$ ;**LAST LINE NEED BE ADJUSTED
0311 1093
0311 1094
0311 1095 :: SPACE FILE FUNCTION - SET SPACE COUNT AND PROPER FUNCTION
0311 1096
0311 1097
51 02 3C 0311 1098 10$: MOVZWL #CDHC_STF,R1 ;SET SPACE FILE FORWARD
50 B5 0314 1099 TSTW R0 ;SPACE FILE FORWARD?
12 14 0316 1100 BGTR 40$ ;IF GTR YES
51 05 9A 0318 1101 MOVZBL #CDHC_STR,R1 ;SET FOR SPACE FILE REVERSE
0A 11 0318 1102 BRB 30$
031D 1103
031D 1104 :: SPACE RECORD FUNCTION - SET SPACE COUNT AND PROPER HARDWARE COMMAND
031D 1105
031D 1106
031D 1107
51 09 9A 031D 1108 20$: MOVZBL #CDHC_SRF,R1 ;SET FOR SPACE RECORD FORWARD
50 B5 0320 1109 TSTW R0 ;SPACE RECORD FORWARD?
06 14 0322 1110 BGTR 40$ ;IF GTR YES
51 07 9A 0324 1111 MOVZBL #CDHC_SRR,R1 ;SET FOR SPACE RECORD REVERSE
50 50 AE 0327 1112 30$: MNEGW R0,R0 ;CONVERT TO POSITIVE COUNT
00B4 C5 50 B0 032A 1113 40$: MOVW R0,UCBSW_MS_SPACNT(R5) ;SET SPACE COUNT
43 12 032F 1114 BNEQ 110$ ;IF NEQ SPACING REQUIRED
51 00 9A 0331 1115 MOVZBL #CDHC_NOP,R1 ;SET FOR NO OPERATION
3E 11 0334 1116 BRB 110$
0336 1117
```

```
0336 1119 :  
0336 1120 : SET CHARACTERISTICS FUNCTION - STORE NEW TAPE CHARACTERISTICS  
0336 1121 :  
0336 1122 : ****TS11/TS04 HAS ONLY ONE CLASS AND TYPE****  
0336 1123 :  
40 A5 38 A3 B0 0336 1124 50$: MOVW IRP$L_MEDIA(R3),UCB$B_DEVCLASS(R5) ;SET NEW DEVICE CLASS AND TYPE  
0336 1125 :  
0336 1126 :  
0336 1127 : SET MODE FUNCTION - STORE NEW TAPE MODE  
0336 1128 :  
0336 1129 :  
42 A5 3A A3 B0 0336 1130 60$: MOVW IRP$L_MEDIA+2(R3),UCB$W_DEVBUFSIZ(R5) ;SET NEW DEFAULT BUFFER SIZE  
7C A5 3C A3 B0 0340 1131 MOVW IRP$L_MEDIA+4(R3),UCB$W_BOFF(R5) ;SAVE NEW TAPE CONTROL PARAMETERS  
51 14 9A 0345 1132 MOVZBL #CDHC_SCH,R1 ;SET DISPATCH INDEX  
2A 11 0348 1133 BRB 110$ ;  
034A 1134 :  
034A 1135 :  
034A 1136 : LOGICAL REWIND AND SET TAPE OFFLINE - CONVERT TO UNLOAD COMMAND  
034A 1137 :  
034A 1138 :  
51 01 9A 034A 1139 70$: MOVZBL #CDHC_UNL,R1 ;SET FOR UNLOAD COMMAND  
25 11 034D 1140 BRB 110$ ;  
034F 1141 :  
034F 1142 :  
034F 1143 : AVAILABLE FUNCTION - Equivalent of REWIND(NOWAIT) and clear of UCB$M_VALID.  
034F 1144 :  
034F 1145 :  
034F 1146 75$:  
00A4 8F B0 034F 1147 MOVW #IOS_REWIND!IOSM_NOWAIT,-; Simulate a REWIND NOWAIT.  
009A C5 0353 1148 UCB$W_FUNC(R5)  
0800 8F AA 0356 1149 BICW #UCB$M_VALID,- ; And clear valid bit.  
64 A5 035A 1150 UCB$W_STS(R5) ; and fall thru to rewind logic.  
035C 1151 :  
035C 1152 :  
035C 1153 : LOGICAL REWIND FUNCTION - CONVERT TO PHYSICAL FUNCTION  
035C 1154 :  
035C 1155 :  
51 03 9A 035C 1156 80$: MOVZBL #CDHC_RWD,R1 ;SET FOR REWIND  
13 11 035F 1157 BRB 110$ ;  
0361 1158 :  
0361 1159 :  
0361 1160 : LOGICAL WRITE EOF OR SENSE MODE FUNCTION - CONVERT TO PHYSICAL FUNCTION  
0361 1161 :  
0361 1162 :  
51 12 A2 0361 1163 90$: SUBW #IOS_SENSEMODE-IOS_READPBLK-9,R1 ;CONVERT TO PHYSICAL****  
0E 11 0364 1164 BRB 110$ ;  
0366 1165 :  
0366 1166 :  
0366 1167 : DENSE FUNCTION CODE - CHECK FOR READ, WRITE, OR WRITECHECK FUNCTION  
0366 1168 :  
0366 1169 :  
51 0A D1 0366 1170 100$: CMPL #IOS_WRITECHECK,R1 ;DATA TRANSFER FUNCTION?  
09 1A 0369 1171 BGTRU 110$ ;IF GTRU NO  
03 009A C5 06 E1 036B 1172 BBC #IOSV_REVERSE,UCB$W_FUNC(R5),110$ ;IF CLEAR,NOT REVERSE  
51 03 A0 0371 1173 ADDW #CDHC_WKR-CDHC_WCK,R1 ;CONVERT TO REVERSE FUNCTION  
0374 1174 :  
0374 1175 :
```

```
0374 1176 : FINISH PREPROCESSING
0374 1177 :
0374 1178 :
0092 C5 51 90 0374 1179 110$: MOVB R1,UCB$B_FEX(R5) :SAVE FUNCTION DISPATCH INDEX
0379 1180 :*****NOTE ABOUT BYTE FOR INDEX
0379 1181 :
0379 1182 :
0379 1183 :CENTRAL FUNCTION DISPATCH
0379 1184 :
0379 1185 :
0379 1186 FDISPATCH:
0379 1187 MOVL UCB$L_IRP(R5),R3 :RETRIEVE ADDR. OF I/O PACKET
037D 1188 BBS #IRP$V_PHYSIO,IRP$W_STS(R3),10$ :IF SET, PHYSICAL I/O FUNCTION
0382 1189 BBS #UCB$V_VALID,UCB$W_STS(R5),10$ :IF SET, VOLUME SOFTWARE VALID
0387 1190 MOVZWL #SS$ VOLINV,R0 :SET VOLUME INVALID STATUS
038C 1191 BRW FCNEXT :**NO CHANGE ON UCB$V_VALID BIT HERE**
038F 1192 :
038F 1193 :
038F 1194 : UNIT IS SOFTWARE VALID OR FUNCTION IS PHYSICAL I/O
038F 1195 :
038F 1196 :
038F 1197 10$:
54 24 A5 D0 038F 1198 MOVL UCB$L_CRB(R5),R4 :GET CSR ADDRESS INTO R4...
54 2C B4 D0 0393 1199 MOVL @CRB$C_INTD+VEC$SL_IDB(R4),R4 :
50 0092 C5 9A 0397 1200 MOVZBL UCB$B_FEX(R5),R0 :GET DISPATCH INDEX
039C 1201 RO,- :DISPATCH TO COMMAND HANDLING ROUTINE
039C 1202 NOP,- :NO OPERATION
039C 1203 UNLOAD,- :REWIND & UNLOAD
039C 1204 SPCFILFOR,- :SPACE FILE FORWARD
039C 1205 REWIND,- :REWIND
039C 1206 DRVCLR,- :DRIVE CLEAR
039C 1207 SPCFILREV,- :SPACE FILE REVERSE
039C 1208 ERASE,- :ERASE
039C 1209 SPCRECREV,- :SPACE RECORD REVERSE
039C 1210 PACKACK,- :PACK ACKNOWLEDGE
039C 1211 SPCRECFOR,- :SPACE RECORD FORWARD
039C 1212 WRITECHECK,- :SIMULATED WRITECHECK
039C 1213 WRITEDATA,- :WRITE DATA FORWARD
039C 1214 READDATA,- :READ DATA FORWARD
039C 1215 WRITECHECKR,- :WRITE CHECK REVERSE
039C 1216 WRITEDATA,- :WRITE DATA(NO REVERSE)
039C 1217 READDATAR,- :READ DATA REVERSE
039C 1218 REREADN,- :REREAD DATA NEXT
039C 1219 REREADP,- :REREAD DATA PREVIOUS
039C 1220 WRITERET,- :WRITE DATA RETRY
039C 1221 READPRESÉT,- :SIMULATED READ PRESET
039C 1222 SETCHAR,- :SIMULATED SET CHARACTERISTIC
039C 1223 GETSTS,- :GET STATUS IMMEDIATE(SENS CHAR.)
039C 1224 WRTTMK,- :WRITE TAPE MARK
039C 1225 WRTTMKR,- :WRITE TAPE MARK RETRY
039C 1226 CLEAN,- :CLEAN
039C 1227 MSGREL,- :MESSAGE BUFFER RELEASE
039C 1228 WRITESUBS,- :WRITE SUBSYSTEM MEMEORY
039C 1229 WRITECHAR,- :WRITE CHARACTERISTICS
039C 1230 >
03D8 1231 :***NOTE INDEX OUT OF BOUND***
```



```
03D8 1233 .SBTTL NOP AND SIMULATED FUNCTIONS
03D8 1234
03D8 1235
03D8 1236 : SET CHARACTERISTIC FUNCTION
03D8 1237 :
03D8 1238
03D8 1239 SETCHAR:
03D8 1240 BICW #UCBSM_MS_SWAP,UCBSW_DEVSTS(R5) ;SET CHARACTERISTIC
68 A5 02 AA 03D8 1240 BICW #UCBSM_MS_SWAP,UCBSW_DEVSTS(R5) ;CLEAR SWAP BIT 1ST
04 EF 03DC 1241 EXTZV #MTSV_FORMAT,- ;GET FORMAT FIELD
04 03DE 1242 #MTSS_FORMAT,-
51 7C A5 03DF 1243 UCBSW_BOFF(R5),R1
51 51 0E B1 03E2 1244 CMPW #MTSK_NORMAL15,R1 ;IS IT INDUSTRIAL COMPATIBLE?
04 12 03E5 1245 BNEQ 5$ ;BR IF NO
68 A5 02 A8 03E7 1246 BISW #UCBSM_MS_SWAP,UCBSW_DEVSTS(R5) ;SET SWAP BIT FOR
03EB 1247 ; SUBSEQUENT IO FUNCTIONS
03EB 1248 5$:
03EB 1249
03EB 1250 :
03EB 1251 : NO OPERATION AND SIMULATED NON-EXISTENT TS11/TS04 HARDWARE COMMAND
03EB 1252 :
03EB 1253
03EB 1254 PACKACK:
64 A5 0800 8F A8 03EB 1255 BISW #UCBSM_VALID,UCBSW_STS(R5) ;PACK ACKNOWLEDGE
03F1 1256 NOP: ;PACKACK implies set volume valid.
03F1 1257 WRITECHECK: ;NO OPERATION
03F1 1258 WRITECHECKR: ;SIMULATED WRITECHECK
03F1 1259 READPRESET: ;SIMULATED WRITECHECK REVERSE
03F1 1260 ;READ IN PRESET
03F1 1261 EXHC 10$ ;EXECUTE HARDWARE COMMAND, IF ANY
039C 31 03F6 1262 10$: BRW FCNEXT ;GOTO FUNCTION EXIT
03F9 1263 ;10$ AS RETRIABLE ERROR OCCURRED
03F9 1264 ;NO RETRIABLE ERROR, NOP ALWAYS SUCCESSFUL
03F9 1265
03F9 1266
```

```
03F9 1268 .SBTTL READ HARDWARE FUNCTIONS
03F9 1269
03F9 1270 :
03F9 1271 : READ HARDWARE FUNCTIONS
03F9 1272 :
03F9 1273 :
03F9 1274 READDATA: ;READ DATA FORWARD
03F9 1275 EXHC 10$ ;EXECUTE HARDWARE COMMAND
00B0 C5 D6 03FE 1276 INCL UCB$L_RECORD(R5) ;INCREMENT RECORD COUNT
0390 31 0402 1277 BRW FCNEXT ;GOTO SUCCESSFUL RETURN
0405 1278 ;10$ HANDLES RETRIABLE ERRORS
0405 1279 10$:
0405 1280 PUSHL R0 ;SAVE R0 HAS TCC
07000000 GF DD 0407 1281 JSB G^ERL$DEVICERR ;LOG BEFORE RETRY
50 8ED0 040D 1282 POPL R0 ;RESTORE
0410 1283 20$:
50 04 D1 0410 1284 CMPL #TCC_REM,R0 ;DID TAPE MOVED
15 13 0413 1285 BEQL 22$ ;YES BRANCH
00B0 C5 97 0415 1286 DECB UCB$B_ERTCNT(R5) ;ANY RETRIES REMAINING?
24 19 0419 1287 BLSS 30$ ;NO, GO AS FATAL
00B0 C5 D6 041B 1288 EXHC 20$ HC RDN ;DO READ AGAIN
036B 31 0423 1289 INCL UCB$L_RECORD(R5) ;INCREMENT RECORD COUNT
0427 1290 BRW RFCNEXT ;SUCCEED, RETURN
042A 1291 22$:
00B0 C5 97 042A 1292 DECB UCB$B_ERTCNT(R5) ;ANY RETRIES REMAINING?
OF 19 042E 1293 BLSS 30$ ;NO, GO AS FATAL ERROR
0430 1294 EXHC 22$ HC RRP ;DO REREAD PREVIOUS
00B0 C5 D6 0438 1295 INCL UCB$L_RECORD(R5) ;INCREMENT RECORD COUNT
0356 31 043C 1296 BRW RFCNEXT ;SUCCEED, RETURN
043F 1297 30$:
0000077A EF 17 043F 1298 JMP FATALERO
0445 1299
0445 1300 :
0445 1301 : REREAD PREVIOUS (SPACE REV,READ FWD)
0445 1302 :
0445 1303 :
0445 1304 REREADP: ;REREAD DATA PREVIOUS
0445 1305 EXHC 10$
0348 31 044A 1306 BRW FCNEXT ;SUCCESS RETURN
044D 1307 10$:
032A 31 044D 1308 BRW FATALERO ;TREATED AS FATAL AS NOW
0450 1309
0450 1310 :
0450 1311 : READ PREVIOUS
0450 1312 :
0450 1313 :
0450 1314 READDATAR: ;READ DATA REVERSE
0450 1315 EXHC 10$
00B0 C5 D7 0455 1316 DECL UCB$L_RECORD(R5) ;DECREMENT RECORD COUNT
0339 31 0459 1317 BRW FCNEXT ;*NOTE*TMK PROBLEM???
045C 1318 10$: ;DO SUCCESSFUL RETURN
50 DD 045C 1319 PUSHL R0 ;RETRIABLE
07000000 GF DD 045C 1320 JSB G^ERL$DEVICERR ;SAVE R0 WHICH HAS TCC CODE
50 8ED0 0464 1321 POPL R0 ;LOG BEFORE RETRY
0467 1322 20$: ;RESTORE
50 04 D1 0467 1323 CMPL #TCC_REM,R0 ;TAPE MOVED?
0467 1324
```

```
0080 15 13 046A 1325 BEQL 22$ :YES
      C5 97 046C 1326 DECB UCB$B_ERTCNT(R5) :ANY RETRIES LEFT?
      24 19 0470 1327 BLSS 30$ :NO, AS FATAL ERROR
00B0 C5 D7 0472 1328 EXHC 20$ HC RDP :DO READ DATA PREVIOUS AGAIN
      0314 31 047A 1329 DECL UCB$L_RECORD(R5) :DECREMENT RECORD COUNT
      047E 1330 BRW RFCNEXT :SUCCESS RETURN
00B0 C5 97 0481 1331 22$: DECB UCB$B_ERTCNT(R5) :ANY RETRIES LEFT?
      OF 19 0485 1332 BLSS 30$ :NO, AS FATAL ERROR
      0487 1333 EXHC 22$ HC RRN :DO REREAD DATA NEXT
00B0 C5 D7 048F 1334 DECL UCB$L_RECORD(R5) :DECREMENT RECORD COUNT
      02FF 31 0493 1335 BRW RFCNEXT :SUCCESS RETURN
      0496 1336 30$:
      0496 1337 BRW FATALERO
      0499 1338
      0499 1339
      0499 1340
      0499 1341 : REREAD DATA NEXT(SPACE FWD, READ REV)
      0499 1342 :
      0499 1343 :
      0499 1344
      0499 1345 REREADN: :REREAD DATA NEXT
      0499 1346 EXHC 10$
      02F4 31 049E 1347 BRW FCNEXT :SUCCESS RETURN
      04A1 1348 10$:
      02D6 31 04A1 1349 BRW FATALERO :AS FATAL ERROR AS NOW
      04A4 1350
      04A4 1351
```



```
04A4 1353 .SBTTL WRITE FUNCTIONS
04A4 1354
04A4 1355 :
04A4 1356 : WRITE DATA
04A4 1357 :
04A4 1358
04A4 1359 WRITEDATA:
46 A5 08 AA 04A4 1360 BICW #<MTSM_HWL>@-16,UCBSL_DEV :WRITE DATA FORWARD
04A8 1361 :DEPEND+2(R5) :CLEAR
04A8 1362 EXHC 10$ :HARDWARE WRITE LOCK BIT
00B0 C5 D6 04AD 1363 INCL UCBSL_RECORD(R5) :INCREMENT RECORD COUNT
02E1 31 04B1 1364 BRW FCNEXT :TAKE FUNCTION EXIT
04B4 1365 10$:
50 DD 04B4 1366 PUSHL R0 :SAVE R0
00000000 GF 16 04B6 1367 JSB G^ERL$DEVICERR :LOG BEFORE RETRY
50 8ED0 04BC 1368 POPL R0 :RESTORE
04BF 1369 20$:
50 04 D1 04BF 1370 CMPL #TCC_REM,R0 :TAPE MOVED?
15 13 04C2 1371 BEQL 22$ :YES
00B0 C5 97 04C4 1372 DECB UCBSB_ERTCNT(R5) :ANY RETRIES LEFT?
24 19 04C8 1373 BLSS 30$ :NO, AS FATAL ERROR
04CA 1374 EXHC 20$ HC WRD :YES, DO WRITE AGAIN
00B0 C5 D6 04D2 1375 INCL UCBSL_RECORD(R5) :INCREMENT RECORD COUNT
02BC 31 04D6 1376 BRW RFCNEXT :TAKE SUCCESS RETURN
04D9 1377 22$:
00B0 C5 97 04D9 1378 DECB UCBSB_ERTCNT(R5) :ANY RETRIES LEFT?
OF 19 04DD 1379 BLSS 30$ :NO, FATAL
04DF 1380 EXHC 22$ HC WRD :DO WRITE DATA RETRY
00B0 C5 D6 04E7 1381 INCL UCBSL_RECORD(R5) :INCREMENT RECORD COUNT
02A7 31 04EB 1382 BRW RFCNEXT :SUCCESS RETURN
04EE 1383 30$:
02B9 31 04EE 1384 BRW FATALERO
04F1 1385
04F1 1386 :
04F1 1387 : WRITE DATA RETRY(SPACE REV,ERASE,WRITE DATA)
04F1 1388 :
04F1 1389
04F1 1390 WRITERET:
04F1 1391 EXHC 10$ :WRITE DATA RETRY
029C 31 04F6 1392 BRW FCNEXT :TAKE SUCCESS RETURN
04F9 1393 10$:
027E 31 04F9 1394 BRW FATALERO :AS FATAL
04FC 1395
04FC 1396 :
04FC 1397 : WRITE SUBSYSTEM MEMORY
04FC 1398 :
04FC 1399
04FC 1400 WRITESUBS:
04FC 1401 EXHC 10$ :WRITE SUBSYSTEM MEMORY
0291 31 0501 1402 BRW FCNEXT :SUCCESS RETURN
0504 1403 10$:
0504 1404
0273 31 0504 1405 BRW FATALERO
0507 1406
0507 1407 :
0507 1408 : WRITE CHARACTERISTICS
0507 1409 : USED TO TELL SUBSYSTEM MSG BUFFER ADDR. & SET CHARACTERISTIC WORD
```

TSDRIVER
V04-000

- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00
WRITE FUNCTIONS 5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1

Page 30
(2)

| | | | | | | | |
|------|----|------|------|------------|------|----------|------------------------|
| | | 0507 | 1410 | : | | | |
| | | 0507 | 1411 | : | | | |
| | | 0507 | 1412 | WRITECHAR: | | | ;WRITE CHARACTERISTICS |
| | | 0507 | 1413 | | | | |
| | | 0507 | 1414 | | EXMC | 108 | |
| 0286 | 31 | 050C | 1415 | | BRW | FCNEXT | ;SUCCESS RETURN |
| | | 050F | 1416 | 108: | | | |
| 0268 | 31 | 050F | 1417 | | BRW | FATALERO | : |
| | | 0512 | 1418 | | | | |

```
0512 1420 .SBTTL POSITIONING FUNCTIONS
0512 1421
0512 1422
0512 1423 : SPACE FILE FORWARD
0512 1424 : NOTE: HARDWARE SKIPFILE COMMAND IS NOT USED.
0512 1425 : SKIPFILE IS SIMULATED BY A SERIES SKIPRECORD COMMANDS.
0512 1426
0512 1427
0512 1428 SPCFILFOR: :SPACE FILE FORWARD
0512 1429 :UCBSW_MS_SPACNT(R5),UCBSW_BOFF(R5) :SAVE NO. OF
7C A5 00B4 C5 B0 0512 1429 MOVW UCBSW_MS_SPACNT(R5),UCBSW_BOFF(R5) :TAPE MARKS TO SKIP
7E A5 00B4 C5 B0 0518 1430 MOVW UCBSW_MS_SPACNT(R5),UCBSW_BCNT(R5) :TAPE MARKS TO SKIP
00D0 C5 00B0 C5 D0 051E 1431 MOVL UCBSL_RECORD(R5),UCBSL_MS_PMPR(R5) :SAVE TAPE POSITION
68 A5 0040 BF A8 0525 1432 BSW #UCBSM_MS_SWE,UCBSW_DEVSTS(R5) :USE OLD TAPE POSITION IF POWERFAIL
052B 1433 :**SOFTWARE EMULATED FUNCTION**
052B 1434 0$: BICW #UCBSM_MS_FEF,UCBSW_DEVSTS(R5) :CLEAR FLAG FOR 1ST EOF SEEN
052B 1435 1$: MOVW #*X7FFF,UCBSW_MS_SPACNT(R5) :SKIP 32,768 RECORDS INSTEAD
00B4 C5 7FFF BF B0 052F 1437 EXHC 10$,HC STF :DO IT
0536 1438 MOVZWL UCBSW_MS_XC(R5),R1 :GET NO. OF RECORDS PASSED
51 00C4 C5 3C 053E 1439 ADDL R1,UCBSL_RECORD(R5) :ADD IT
00B0 C5 51 C0 0543 1440 BBC #MISV_EOF,UCBSL_DEVDEPEND(R5),0$ :BR IF DIDN'T SEE TAPE MARK
DE 44 A5 11 E1 0548 1441 DECW UCBSW_BCNT(R5) :DECREMENT TAPE MARK PASSED
7E A5 13 E1 0550 1442 BBC #DEVS0_MNT,- :BR IF NOT MOUNTED
05 38 A5 18 E1 0552 1443 BBC UCBSL_DEVCHAR(R5),2$ :BR IF MOUNTED NOT FOREIGN
34 38 A5 18 E1 0555 1445 BBC #DEVS0_FOR,- :BR IF MOUNTED NOT FOREIGN
0557 1446 UCBSL_DEVCHAR(R5),5$ :
055A 1447 2$: BBC #UCBSV_MS_FEF,UCBSW_DEVSTS(R5),4$ :BR IF 1ST TMK
2B 68 A5 00 E1 055A 1448 CMPW #1,UCBSW_MS_XC(R5) :**1 RECORD=TAPE MARK??**
00C4 C5 01 B1 055F 1449 BNEQ 5$ :BR IF NO
00B4 C5 01 B0 0566 1450 MOVW #1,UCBSW_MS_SPACNT(R5) :SKIP 1 TMK REVERSE
7E A5 B6 056B 1452 EXHC 10$,HC STR :
00B0 C5 D7 0573 1453 INCW UCBSW_BCNT(R5) :BACKUP 1 TMK PASSED
50 09A0 BF 3C 0576 1454 DECL UCBSL_RECORD(R5) :UPDATE TAPE POSITION
00C4 C5 7C A5 7E A5 A3 057A 1455 MOVZWL #SS$ ENDOFVOLUME,R0 :YES, DOUBLE TMKS=ENDOFVOLUME
7C A5 7E A5 A3 057F 1456 SUBW3 UCBSW_BCNT(R5),UCBSW_BOFF(R5),UCBSW_MS_XC(R5) :GET NO. OF
0587 1457 : TAPE MARKS PASSED
020B 31 0587 1458 BRW FCNEXT :GO EXIT
68 A5 01 A8 058A 1459 4$: BSW #UCBSM_MS_FEF,UCBSW_DEVSTS(R5) :SET 1ST EOF
058E 1461 5$: TSTW UCBSW_BCNT(R5) :PASSED ALL TAPE MARKS
7E A5 B5 058E 1462 BNEQ 1$ :NO, GO BACK
00C4 C5 7C A5 B0 0591 1463 MOVW UCBSW_BOFF(R5),UCBSW_MS_XC(R5) :YES,COPY TMKS PASSED
01F9 31 0599 1465 BRW FCNEXT :GO EXIT
01DB 31 059C 1466 10$: BRW FATALERO :TAKE FAILURE RETURN
059C 1467
059F 1468
059F 1469
059F 1470 : SPACEFILE REVERSE
059F 1471
059F 1472
059F 1473 SPCFILREV: :SPACE FILE REVERSE
7C A5 00B4 C5 B0 059F 1474 MOVW UCBSW_MS_SPACNT(R5),UCBSW_BOFF(R5) :SAVE NO. OF
7E A5 00B4 C5 B0 05A5 1475 MOVW UCBSW_MS_SPACNT(R5),UCBSW_BCNT(R5) :TAPE MARKS TO SKIP
00D0 C5 00B0 C5 D0 05AB 1476 MOVL UCBSL_RECORD(R5),UCBSL_MS_PMPR(R5) :SAVE TAPE POSITION
```



```
68 A5 0040 8F A8 05B2 1477 B1SW #UCBSM_MS_SWE,UCBSW_DEVSTS(R5) ;USE OLD TAPE POSITION IF POWERFAIL
05B8 1478 ;**SOFTWARE EMULATED FUNCTION**
05B8 1479 18:
00B4 C5 7FFF 8F B0 05B8 1480 MOVW #*X7FFF,UCBSW_MS_SPACNT(R5) ;SKIP 32,768 RECORDS INSTEAD
05BF 1481 EXHC 10$,HC_SRF ;DO IT
05C7 1482 BBC #MT$V_BOT,- ; If we ran into BOT, treat as if
17 44 A5 E0 05C9 1483 UCBSL_DEVDEPEND(R5),5$ ; we were done.
51 00C4 C5 3C 05CC 1484 UCBSW_MS_XC(R5),R1 ;GET NO. OF RECORDS PASSED
00B0 C5 51 C2 05D1 1485 SUBL R1,UCBSL_RECORD(R5) ;SUBTRACT
DD 44 A5 11 E1 05D6 1486 BBC #MT$V_EOF,UCBSL_DEVDEPEND(R5),1$ ;BR IF DIDN'T SEE TAPE MARK
7E A5 B7 05DB 1487 DECW UCBSW_BCNT(R5) ;DECREMENT TAPE MARK PASSED
7E A5 B5 05DE 1488 TSTW UCBSW_BCNT(R5) ;PASSED ALL TAPE MARKS?
D5 12 05E1 1489 BNEQ 1$ ;NO, BR BACK
05E3 1490 5$:
7E A5 A3 05E3 1491 SUBW3 UCBSW_BCNT(R5),- ; Calculate number of tape
7C A5 05E6 1492 UCBSW_BOFF(R5),- ; marks passed.
00C4 C5 05E8 1493 UCBSW_MS_XC(R5)
01A7 31 05EB 1494 BRW FCNEXT ;GO EXIT
01B9 31 05EE 1495 10$:
05EF 1496 BRW FATALERO
05F1 1497
05F1 1498 ; SPACE RECORD FORWARD
05F1 1499
05F1 1500
05F1 1501
05F1 1502 SPCRECFOR: ;SPACE RECORD FORWARD
05F1 1503 EXHC 10$
SC 44 A5 11 E1 05F6 1504 BBC #MT$V_EOF,UCBSL_DEVDEPEND(R5),8$ ;BR IF NO TMK
00C4 C5 01 B1 05FB 1505 CMPW #1,UCBSW_MS_XC(R5) ;**1 RECORD=TMK?**
55 12 0600 1506 BNEQ 8$ ;BR IF NO
13 E1 0602 1507 BBC #DEV$V_MNT,- ;BR IF NOT MOUNTED
05 38 A5 0604 1508 UCBSL_DEVCHAR(R5),2$
4B 38 A5 E1 0607 1509 BBC #DEV$V_FOR,- ;BR IF MOUNTED NOT FOREIGN
0609 1510 UCBSL_DEVCHAR(R5),8$
00B0 C5 D5 060C 1511 2$:
45 13 0610 1512 TSTL UCBSL_RECORD(R5) ;WAS AT BOT?
00B4 C5 01 B0 0612 1513 BEQL 8$ ;BR IF YES
0617 1514 MOVW #1,UCBSW_MS_SPACNT(R5) ;SKIP 1 RECORD REVERSE
00B4 C5 01 B0 061F 1515 EXHC 10$,HC_SRF
0624 1516 MOVW #1,UCBSW_MS_SPACNT(R5) ;SKIP 1 RECORD REVERSE
00B4 C5 01 B0 062C 1517 EXHC 10$,HC_SRF
0631 1518 MOVW #1,UCBSW_MS_SPACNT(R5) ;SKIP 1 RECORD FORWARD
0C 44 A5 11 E1 0639 1519 EXHC 10$,HC_SRF
50 09A0 8F 3C 063E 1520 BBC #MT$V_EOF,UCBSL_DEVDEPEND(R5),6$ ;BR IF NO TMK
00C4 C5 B4 0643 1521 MOVZWL #$$$_ENDOFVOLUME,R0 ;WAS AT ENDOFVOLUME
014B 31 0647 1522 CLRW UCBSW_MS_XC(R5) ;NO RESULTANT MOVEMENT
064A 1523 BRW FCNEXT ;RETURN
00B4 C5 01 B0 064A 1524 6$:
064A 1525 MOVW #1,UCBSW_MS_SPACNT(R5) ;SKIP 1 RECORD FORWARD
064F 1526 EXHC 10$,HC_SRF
0657 1527 8$:
51 00C4 C5 3C 0657 1528 MOVZWL UCBSW_MS_XC(R5),R1 ;GET NO. OF RECORDS PASSED
00B0 C5 51 C0 065C 1529 ADDL R1,UCBSL_RECORD(R5) ;UPDATE
0131 31 0661 1530 BRW FCNEXT
0113 31 0664 1531 10$:
0664 1532 BRW FATALERO
0667 1533
```

```
0667 1534 :  
0667 1535 : SPACE RECORD REVERSE  
0667 1536 :  
0667 1537 :  
0667 1538 SPCRECREV: ;SPACE RECORD REVERSE  
0667 1539 EXHC 10$ ;  
066C 1540 BBS #MTSV_BOT,- ; If we ran into BOT, treat as if  
066E 1541 UCB$[DEVDEPEND(R5),5$ ; we were done.  
51 0A 44 A5 E0 0671 1542 MOVZWL UCB$[MS_XC(R5),R1 ;GET NO. OF RECORDS PASSED  
0080 C5 51 C2 0676 1543 SUBL R1,UCB$[RECORD(R5) ;UPDATE  
0117 31 067B 1544 5$: ;  
067B 1545 BRW FCNEXT ;  
00F9 31 067E 1546 10$: ;  
067E 1547 BRW FATALERO ;  
0681 1548 :  
0681 1549 :  
0681 1550 : REWIND  
0681 1551 :  
0681 1552 :  
0681 1553 REWIND: ;REWIND  
0681 1554 EXHC 10$ ;  
46 A5 01 A8 0686 1555 BSW #<MTSM_BOT@-16>,UCB$[DEVDEPEND+2(R5) ;MARK BOT  
46 A5 10 AA 068A 1556 BICW #<MTSM_LOST@-16>,UCB$[DEVDEPEND+2(R5) ;CLEAR POSITION-LOST  
0080 C5 D4 068E 1557 CLRL UCB$[RECORD(R5)  
0100 31 0692 1558 BRW FCNEXT  
0695 1559 10$: ;  
00E2 31 0695 1560 BRW FATALERO  
0698 1561
```

```
0698 1563 .SBTTL FORMAT COMMANDS
0698 1564
0698 1565 :
0698 1566 : WRITE TAPE MARK
0698 1567 :
0698 1568
0698 1569 WRTTMK: ;WRITE TAPE MARK
46 A5 08 AA 0698 1570 BICW #<MTSM_HWL>8-16,UCBSL_DEVDEPEND+2(R5) ;CLEAR
069C 1571 ; WRITE LOCK BIT FIRST
069C 1572 EXHC 10$
0080 C5 D6 06A1 1573 INCL UCBSL_RECORD(R5) ;INCREMENT RECORD COUNT
00ED 31 06A5 1574 BRW FCNEXT ;GOTO EXIT
06A8 1575 10$:
50 DD 06A8 1576 PUSHL R0 ;SAVE R0
00000000 GF 16 06AA 1577 JSB G^ERL$DEVICERR ;LOG BEFORE RETRY
50 BED0 06B0 1578 POPL R0 ;RESTORE
06B3 1579 20$:
50 04 D1 06B3 1580 CMPL #TCC_REM,R0 ;TAPE MOVED?
15 13 06B6 1581 BEQL 22$ ;YES
0080 C5 97 06B8 1582 DECB UCBSB_ERTCNT(R5) ;ANY RETRIES LEFT?
24 19 06BC 1583 BLSS 30$ ;NO, FATAL
06BE 1584 EXHC 20$,HC WTM ;DO IT AGAIN
0080 C5 D6 06C6 1585 INCL UCBSL_RECORD(R5) ;INCREMENT RECORD COUNT
00C8 31 06CA 1586 BRW RFCNEXT ;RETURN
06CD 1587 22$:
0080 C5 97 06CD 1588 DECB UCBSB_ERTCNT(R5) ;ANY RETRIES LEFT?
OF 19 06D1 1589 BLSS 30$ ;NO, FATAL
06D3 1590 EXHC 22$,HC WTR ;DO WRITE TAPE MARK RETRY
0080 C5 D6 06DB 1591 INCL UCBSL_RECORD(R5) ;INCREMENT RECORD COUNT
00B3 31 06DF 1592 BRW RFCNEXT ;
06E2 1593
0095 31 06E2 1594 30$: BRW FATALERO ;BRANCH FATAL ERROR
06E5 1595 :
06E5 1596 : WRITE TAPE MARK RETRY(SPACE REV,ERASE,WRITE TAPE MARK)
06E5 1597 :
06E5 1598
06E5 1599 WRTTMKR: ;WRITE TAPE MARK RETRY
06E5 1600 EXHC 10$
00A8 31 06EA 1601 BRW FCNEXT ;GO EXIT
06ED 1602 10$:
00BA 31 06ED 1603 BRW FATALERO ;FATAL AS NOW
06F0 1604 :
06F0 1605 : ERASE
06F0 1606 :
06F0 1607
06F0 1608 ERASE: ;ERASE
06F0 1609 EXHC 10$
009D 31 06F5 1610 BRW FCNEXT ;
06F8 1611 10$:
007F 31 06F8 1612 BRW FATALERO
06FB 1613
```



```

06FB 1615 .SBTTL CONTROL COMMANDS
06FB 1616
06FB 1617 :
06FB 1618 : CONTROL COMMANDS
06FB 1619 :
06FB 1620
06FB 1621 MSGREL:
06FB 1622 EXHC 10$ ;MESSAGE BUFFER RELEASE
0092 31 0700 1623 BRW FCNEXT ;
0703 1624 10$:
0703 1625
0074 31 0703 1626 BRW FATALERO
0706 1627
0706 1628 UNLOAD: ;
0706 1629 EXHC 10$ ;
0087 31 070B 1630 BRW FCNEXT ;
070E 1631 10$:
0069 31 070E 1632 BRW FATALERO
0711 1633
0711 1634 CLEAN: ;CLEAN
0711 1635 EXHC 10$ ;
007C 31 0716 1636 BRW FCNEXT ;
0719 1637 10$:
005E 31 0719 1638 BRW FATALERO
071C 1639

```

```
071C 1641 .SBTTL .INITIALIZE AND GET STATUS
071C 1642
071C 1643
071C 1644 : DRIVE INITIALIZE
071C 1645 :
071C 1646
071C 1647 DRVCLR:                                ;DRIVE INITIALIZE
071C 1648
0071 31 0721 1649      EXHC 10$
0724 1650      BRW  FCNEXT
0053 31 0724 1651      10$:
0727 1652      BRW  FATALERO
0727 1653
0727 1654 : GET STATUS (END MESSAGE ONLY)
0727 1655 :
0727 1656
0727 1657 GETSTS:
0727 1658      EXHC 10$
0727 1659      BICW  #<MTSM_BOT!- :CLEAR BITS IN UCBSL_DEVDEPEND+2
0730 1660      MTSM_EOF!- :
0730 1661      MTSM_EOT!- :END OF TAPE
0730 1662      MTSM_HWL>2-16,UCBSL_DEVDEPEND+2(R5) ;
0730 1663      #MS_XSRO_V BOT,- :AT BOT?
0732 1664      UCBSW_MS_XSRO(R5),1$ :BR IF NO
0736 1665      CLRL UCBSL_RECORD(R5) ;CLEAR RECORD COUNT
073A 1666      BICW #<MTSM_BOT>2-16>,UCBSL_DEVDEPEND+2(R5) ;SET BOT
073E 1667      BICW #<MTSM_LOST>2-16>,UCBSL_DEVDEPEND+2(R5) ;CLEAR LOST BIT
0742 1668 1$:
0742 1669      BBC  #MS_XSRO_V TMK,- :AT TAPE MARK
0744 1670      UCBSW_MS_XSRO(R5),2$ :BR IF NO
0748 1671      BICW #<MTSM_EOF>2-16>,UCBSL_DEVDEPEND+2(R5) ;SET EOF
074C 1672 2$:
074C 1673      BBC  #MS_XSRO_V WLK,- :WRITE-LOCKED?
074E 1674      UCBSW_MS_XSRO(R5),3$ :BR IF NO
0752 1675      BICW #<MTSM_HOLA-16>,UCBSL_DEVDEPEND+2(R5) ;SET WRITE-LOCKED
0756 1676 3$:
0756 1677      BBC  #MS_XSRO_V EOT,- :END OF TAPE
0758 1678      UCBSW_MS_XSRO(R5),4$ :BR IF NO
075C 1679      BICW #<MTSM_LOST>2-16>,UCBSL_DEVDEPEND+2(R5) ;CLEAR POS.LOST
0760 1680      BICW #<MTSM_EOT>2-16>,UCBSL_DEVDEPEND+2(R5) ;SET END OF TAPE
0764 1681      MOVZWL #SS$_ENDOFTAPE,R0 ;PUT IN RETURN STATUS
0769 1682 4$:
0769 1683      BBS  #MS_XSRO_V ONL,- :CHECK IF ONLINE?
076B 1684      UCBSW_MS_XSRO(R5),6$ :BR IF YES
076F 1685
076F 1686      MOVZWL #SS$_MEDOFFL,R0 ;RETURN MEDIUM-OFFLINE
0774 1687 6$:
0774 1688      BRW  FCNEXT
0777 1689      10$:
0777 1690      BRW  FATALERO ;TREAT AS FATAL
077A 1691
```

```
077A 1693 .SBTTL COMPLETION PROCESSING
077A 1694 :
077A 1695 : FATALERR - FINISHING UP THE I/O REQUEST PROCESSING WHEN THE OPERATION
077A 1696 : ENDS WITH FATAL OR HARD ERROR.
077A 1697 : RO HAS THE FINAL STATUS CODE ALREADY.
077A 1698 :
077A 1699 :
077A 1700 FATALERO: ;NO ERROR CODE IN RO
077A 1701 MOVZWL #SS$_DRVERR,RO ;GIVE IT ONE FOR NOW
077F 1702 FATALERR:
077F 1703 CLRW UCBSW_MS_XC(R5) ;MAKE SURE NOTHING XFERRED/SKIPPED
0783 1704
0783 1705 CMPW #SS$_MEDOFL,RO ; See if error is MEDIA OFF LINE.
0788 1706 BEQL FCNEXT ; If so, then branch around logging error.
078A 1707 PUSHL RO ;SAVE FINAL STATUS
078C 1708 JSB G*ERL$DEVICERR ;LOG DEVICE ERROR
0792 1709 POPL RO
0795 1710 RFCNEXT: ;SUCCESS RETURN AFTER RETRY
0795 1711 FCNEXT:
0795 1712 BICW #<UCBSM_MS_RPI!UCBSM_MS_SWE>,UCBSW_DEVSTS(R5) ;ASSURE FLAGS CLEARED
0798 1713 PUSHL RO ;SAVE FINAL STATUS
079D 1714 JSB G*IOCS$DIAGBUFILL ;FILL DIAGNOSTIC BUFFER IF PRESENT
07A3 1715 MOVW UCBSW_MS_XC(R5),2(SP) ;SET BYTES XFERRED OR RECORDS/FILES SKIPPED
07A9 1716 BLBS (SP),70$ ;IF LBS SUCCESSFUL COMPLETION
07AC 1717 MOVL UCBSL_IRP(R5),R4 ;GET ADDRESS OF CURRENT I/O PACKET
07B0 1718 BBC #IRP$V_VIRTUAL,IRP$W_STS(R4),70$ ;IF CLR, NOT VIRTUAL FUNCTION
07B5 1719 MOVL IRP$W_WIND(R4),R4 ;GET ADDRESS OF WINDOW BLOCK
07B9 1720 CLRW UCBSW_NMAP(R4) ;CLEAR NUMBER OF MAPPING POINTERS
07BC 1721 MOVL UCBSL_VCB(R5),R4 ;GET ADDRESS OF VCB LISTHEAD
07C0 1722 MOVAB UCBSL_IOQFL(R5),R2 ;GET ADDRESS OF I/O QUEUE
07C4 1723 MOVL R2,R3 ;SET ADDRESS OF PREVIOUS ENTRY
07C7 1724 60$: MOVL (R3),R3 ;GET ADDRESS OF NEXT ENTRY
07CA 1725 CMPL R3,R2 ;END OF LIST?
07CD 1726 BEQL 70$ ;IF EQL YES
07CF 1727 BBC #IRP$V_VIRTUAL,IRP$W_STS(R3),60$ ;IF CLR, NOT VIRTUAL FUNCTION
07D4 1728 MOVL 4(R3),R3 ;RETRIEVE ADDRESS OF PREVIOUS ENTRY
07D8 1729 REMQUE 2(R3),R1 ;REMOVE ENTRY FROM DRIVER QUEUE
07DC 1730 INSQUE (R1),24(R4) ;INSERT ENTRY IN BLOCKED I/O LIST
07E0 1731 BRB 60$
07E2 1732 70$: POPL RO ;RETRIEVE FINAL STATUS
07E5 1733 MOVL UCBSL_DEVDEPEND(R5),R1 ;SET MAGTAPE STATUS AND CHARACTERISTIC
07E9 1734 .IF DF TS TRACE
07E9 1735 BSBW TRACE_STATOS ; Trace final I/O status.
07E9 1736 .ENDC
07E9 1737 REQCOM ;COMPLETE REQUEST
07EF 1738
```



```
07EF 1740 .SBTTL  HARDWARE COMMAND EXECUTOR
07EF 1741 :+
07EF 1742 : HCEX - EXECUTES HARDWARE COMMAND
07EF 1743 :
07EF 1744 : THIS ROUTINE IS CALLED VIA A BSB WITH A WORD IMMEDIATELY FOLLOWING THAT
07EF 1745 : SPECIFIES THE ADDRESS OF AN (RETRIABLE) ERROR ROUTINE. ALL DATA IS ASSUMED TO HAVE
07EF 1746 : BEEN SET UP IN THE UCB BEFORE THE CALL. THE COMMAND PACKET IS APPROPRIATELY
07EF 1747 : SETUP AND INITIATED BY LOADING THE ADDR. OF COMMAND PACKET INTO THE
07EF 1748 : TS11/TS04 DEVICE REGISTER, TSDB. THEN, A WAITFOR INTERRUPT IS EXECUTED
07EF 1749 : AND WHEN THE INTERRUPT OCCURS, CONTROL IS RETURNED TO THE CALLER.
07EF 1750 : THE ROUTINE MAINLY DEALS WITH THE HARDWARE INTERFACE.
07EF 1751 :
07EF 1752 : INPUTS:
07EF 1753 : R0=HARDWARE COMMAND TABLE DISPATCH INDEX
07EF 1754 : R4=EQUIVALENT CSR ADDR. FOR TS11/TS04
07EF 1755 : R5=DEVICE UNIT UCB ADDRESS
07EF 1756 :
07EF 1757 : 00(SP) = RETURN ADDRESS OF CALLER
07EF 1758 : 04(SP) = RETURN ADDRESS OF CALLER'S CALLER
07EF 1759 :
07EF 1760 : IMMEDIATELY FOLLOWING INLINE AT THE CALL SITE IS A WORD WHICH HAS
07EF 1761 : A BRANCH DESTINATION TO AN ERROR RETRY ROUTINE, IF APPROPRIATE.
07EF 1762 : OUTPUTS:
07EF 1763 : THE DRIVE STATUS, SUCH AS BOT, EOT, ETC, ARE RECORDED IN UCB.
07EF 1764 :
07EF 1765 : THERE ARE THREE EXITS FROM THIS ROUTINE:
07EF 1766 : 1) NORMAL RETURN,
07EF 1767 : 2) FATAL OR HARD ERROR EXIT, AND
07EF 1768 : 3) RETRIABLE ERROR RETURN.
07EF 1769 : WHEN EXITS, R0 HAS THE FINAL STATUS CODE IF NORMAL OR FATAL,
07EF 1770 : R0 HAS TERMINATION CODE, 4 OR 5, IF RETRIABLE.
07EF 1771 : THE DRIVE STATUS IS RECORDED INTO UCB WHILE PROCESSING TERMINATION CODE
07EF 1772 :
07EF 1773 :
07EF 1774 : HCEX:
07EF 1775 : POPL  UCBSL_DPC(R5) ;SAVE DRIVER PC VALUE
00DC 009C C5 8ED0 07EF 1776 : MOVZBL #20,UCBSL_MS_TIMEOUT(R5) ; Initialize timeout to 20 seconds.
07F4 1777 : CLRW  UCBSB_MS_DPN(R5) ;CLEAR DATA PATH NO. & PURGE ERROR
00C6 C5 B4 07F9 1778 : CLRQ  UCBSL_MS_DPR(R5) ;ZERO DATAPATH REG. & FINAL MAP REG.
00C8 C5 7C 07FD 1779 : CLRW  UCBSW_MS_XC(R5) ;INITIALIZE COUNT
00C4 C5 B4 0801 1780 : MOVB  R0,UCBSB_CEX(R5) ;SAVE CASE INDEX
0093 C5 50 90 0805 1781 : MOVL  UCBSL_MS_TSPT1(R5),R1 ;GET COMMAND PACKET POINTER
51 00B6 C5 D0 080A 1782 : MOVW  HCTAB[R0],MS_CPHD(R1) ;LOAD COMMAND PACKET HEAD WORD
61 F824 CF40 B0 080F
```

| | | | | | | | | |
|-------|------|----|----|------|------|------|--------------------------------------|--|
| 10 A1 | FFFF | BF | B0 | 0815 | 1784 | MOVW | #*XXXX,MS_MHD(R1) | :MARK MSG HEAD TO ENSURE MSG BUFFER RETURNED |
| 05 68 | A5 | 0C | E5 | 081B | 1785 | BBCC | #UCB\$V,MS_VCK,UCB\$W_DEV\$S(R5),7\$ | :BR IF NOT VOLUME CHECK |
| 61 | 4000 | BF | A8 | 0820 | 1786 | BISW | #MS_CPHD_M_CVC,MS_CPHD(R1) | :YES, FLAG TO CLEAR VOLUME CHECK |
| | | | | 0825 | 1787 | | | |
| | | | | 0825 | 1788 | CASE | RO,<- | :DISPATCH TO PROPER COMMAND ROUTINE |
| | | | | 0825 | 1789 | | PNOP,- | :NOP |
| | | | | 0825 | 1790 | | PMIS,- | :UNLOAD |
| | | | | 0825 | 1791 | | PPOS,- | :SPACE FILE FORWARD |
| | | | | 0825 | 1792 | | PPOS,- | :REWIND |
| | | | | 0825 | 1793 | | PMIS,- | :DRIVE CLEAR |
| | | | | 0825 | 1794 | | PPOS,- | :SPACE FILE REVERSE |
| | | | | 0825 | 1795 | | PMIS,- | :ERASE |
| | | | | 0825 | 1796 | | PPOS,- | :SPACE RECORD REVERSE |
| | | | | 0825 | 1797 | | PNOP,- | :SIMULATED PACK ACKNOWLEDGE |
| | | | | 0825 | 1798 | | PPOS,- | :SPACE RECORD FORWARD |
| | | | | 0825 | 1799 | | PNOP,- | :SIMULATED WRITECHECK |
| | | | | 0825 | 1800 | | PXFR,- | :WRITE DATA FORWARD |
| | | | | 0825 | 1801 | | PXFR,- | :READ DATA FORWARD |
| | | | | 0825 | 1802 | | PNOP,- | :SIMULATED WRITE CHECK REVERSE |
| | | | | 0825 | 1803 | | PXFR,- | :WRITE DATA (NO REVERSE) |
| | | | | 0825 | 1804 | | PXFR,- | :READ DATA REVERSE |
| | | | | 0825 | 1805 | | PXFRD,- | :REREAD DATA NEXT |
| | | | | 0825 | 1806 | | PXFRD,- | :REREAD DATA PREVIOUS |
| | | | | 0825 | 1807 | | PXFR,- | :WRITE DATA RETRY |
| | | | | 0825 | 1808 | | PNOP,- | :SIMULATED READ PRESET |
| | | | | 0825 | 1809 | | PNOP,- | :SIMULATED SET CHARACTERISTIC |
| | | | | 0825 | 1810 | | PMIS,- | :GET STATUS IMMEDIATE(SENS CHAR.) |
| | | | | 0825 | 1811 | | PMIS,- | :WRITE TAPE MARK |
| | | | | 0825 | 1812 | | PMIS,- | :WRITE TAPE MARK RETRY |
| | | | | 0825 | 1813 | | PMIS,- | :CLEAN |
| | | | | 0825 | 1814 | | PMIS,- | :MESSAGE BUFFER RELEASE |
| | | | | 0825 | 1815 | | PXFR,- | :WRITE SUBSYSTEM MEMORY |
| | | | | 0825 | 1816 | | PWCH,- | :WRITE CHARACTERISTICS |
| | | | | 0825 | 1817 | | > | : |
| | | | | 0861 | 1818 | | | : |

```
0861 1820 :+PNOP - NO OPERATION ON HARDWARE FOR MANY SIMULATED FUNCTIONS
0861 1821 :THEY ARE: NOP,PACK ACKNOWLEDGE,WRITECHECK,WRITE CHECK REVERSE,
0861 1822 :READ IN PRESET,SET CHARACTERISTICS.
0861 1823 :THE ROUTINE SIMPLY RETURNS.
0861 1824 :
0861 1825 PNOP:
0861 1826 RET:
009C 50 01 3C 0861 1827 MOVZWL #SS$ NORMAL,R0 ;ALWAYS SUCCESS
009C C5 02 C0 0864 1828 ADDL #2,UCB$L_DPC(R5) ;ADJUST TO CORRECT RETURN
009C 009C D5 17 0869 1829 JMP @UCB$L_DPC(R5) ;RETURN TO DRIVER
086D 1830
086D 1831
086D 1832 : PPOS - CONSTRUCT COMMAD PACKET FOR POSITIONING COMMANDS:
086D 1833 : SPACE RECORDS FORWARD, SPACE RECORDS REVERSE, SKIP TAPE MARKS FORWARD,
086D 1834 : SPACE TAPE MARKS REVERSE, AND REWIND.
086D 1835
086D 1836 PPOS:
00 50 03 91 086D 1837 CMPB #CDHC_RWD,R0 ;REWIND COMMAND?
00 2A 12 0870 1838 BNEQ 5$ ;NO
00 05 E1 0872 1839 DSBINT ;YES, DISABLE INTERRUPTS
00 64 A5 0878 1840 BBC #UCB$V_POWER,- ;
00 0090 31 087A 1841 UCB$W_STS(R5),1$ ; Continue if NO powerfail
00 64 00BE C5 B0 087D 1842 BRW PWRFLT ; Branch around if we had POWERFAIL.
00 0193 31 0880 1843 1$:
00 00BE C5 B0 0880 1844 MOVW UCB$W_MS_TSPT3(R5),(R4) ;LOAD COMMAND POINTER
00 00BE C5 B0 0885 1845 WFIKPCB MSTMT,#D300 ;TIMEOUT FOR 5 MIN.'S FOR 2400 FEET TAPE
00 00BE C5 B0 0893 1846 IOFORK ;MAKE IT FORK FIRST
00 00BE C5 B0 0899 1847 BRW XTC ;GO PROCESS TERMINATION CODE
00 00BE C5 B0 089C 1848 5$:
00 00BE C5 B0 089C 1849 MOVW UCB$W_MS_SPACNT(R5),MS_BACT(R1) ;LOAD THE COUNT
00 00BE C5 B0 08A2 1850 MOVW UCB$W_MS_SPACNT(R5),UCB$W_MS_XC(R5) ;COPY COUNT
00 00BE C5 B0 08A9 1851 ;FALL INTO CODE TO LOAD COMMAND
00 00BE C5 B0 08A9 1852 MOVZWL UCB$W_MS_SPACNT(R5),- ; Maximum size record takes one second
00 00BE C5 B0 08AD 1853 UCB$L_MS_TIMEOUT(R5) ; to skip (approximately).
00 00BE C5 B0 08B0 1854 CMPL #11*60,- ; Compare time to skip entire tape to
00 00BE C5 B0 08B6 1855 UCB$L_MS_TIMEOUT(R5) ; time to skip this # records.
00 00BE C5 B0 08B9 1856 BGEQ 10$ ; GEQ implies skipping small # records
00 00BE C5 B0 08BB 1857 MOVZWL #11*60,- ; Else use maximum time to skip whole
00 00BE C5 B0 08BF 1858 UCB$L_MS_TIMEOUT(R5) ; tape.
00 00BE C5 B0 08C2 1859 BRB 20$ ; And branch around.
00 00BE C5 B0 08C4 1860 10$:
00 00BE C5 B0 08C9 1861 20$:
00 00BE C5 B0 08C9 1862 ADDL #2,UCB$L_MS_TIMEOUT(R5) ; Add in fudge factor for small skips.
00 00BE C5 B0 08C9 1863 :+PMIS - CONSTRUCT COMMAND PACKET FOR FORMAT COMMANDS: WRITE TAPE MARK,
00 00BE C5 B0 08C9 1864 : ERASE,WRITE TAPE MARK RETRY; CONTROL COMMANDS: MESSAGE BUFFER RELEASE,
00 00BE C5 B0 08C9 1865 : UNLOAD, & CLEAN; INITIALIZE COMMAND: DRIVE INITIALIZE; AND GET STATUS
00 00BE C5 B0 08C9 1866 : COMMAND: GET STATUS IMMEDIATE.
00 00BE C5 B0 08C9 1867
00 00BE C5 B0 08C9 1868 PMIS:
00 00BE C5 B0 08C9 1869 BRW LDTSDB ;GO LOAD DEVICE REGISTER
00 00BE C5 B0 08CC 1870
00 00BE C5 B0 08CC 1871 : PWCH - CONSTRUCT COMMAND PACKET FOR WRITE CHARACTERISTIC COMMAND
00 00BE C5 B0 08CC 1872
00 00BE C5 B0 08CC 1873 PWCH:
00 00BE C5 B0 08CC 1874 MOVL UCB$L_MS_TSPT2(R5),MS_BACT(R1) ; R1 POINTS TO COMMAND PACKET
00 00BE C5 B0 08D2 1875 ADDL #8,MS_BACT(R1) ;STORE CHAR. BUFFER ADDR.
00 00BE C5 B0 08D6 1876 MOVW #8,MS_CNT(R1) ;POINT TO CHAR. BUFFER NOW
00 00BE C5 B0 08D6 1876 ;STORE BYTE COUNT FOR CHAR. DATA
```



```
08 A1 00BA C5 D0 08DA 1877      MOVL      UCBSL_MS_TSPT2(R5),MS_MBA0(R1)      ;STORE MESSAGE BUFFER ADDR.
      08 A1 10 C0 08E0 1878      ADDL      #16,MS_MBA0(R1)      ; AS CHAR. DATA
      0C A1 0E B0 08E4 1879      MOVW      #14,MS_LNTH(R1)      ;LENGTH OF CHAR. DATA=14.
      0E A1 B4 08E8 1880      CLRW      MS_CHWD(R1)      ;ZERO CHARACTERISTIC WORD
      08E8 1881      ;
      08E8 1882      ; NOW, COMMAND PACKET IS SETUP, READY TO LOAD DEVICE REGISTER
      08E8 1883      ;
      08E8 1884      ;
      08E8 1885      LDTSD8:      ;TS11/TS04 CSR EQUIVALENT=TSDB
      08E8 1886      DSBINT      ;DISABLE INTERRUPTS
1A 64 A5 05 E0 08F1 1887      BBS      #UCBSV_POWER,UCBSW_STS(R5),PWRFL1 ;BR IF POWERFAILED
      64 00BE C5 B0 08F6 1888      MOVW      UCBSW_MS_TSPT3(R5),(R4) ;LOAD THE COMMAND POINTER
      08FB 1889      WFIKPC      MSTMT,UCBSL_MS_TIMEOUT(R5)
      0907 1890      IOFORK      ;MAKE IT FORK FIRST
      011F 31 090D 1891      BRW      XTC      ;PROCESS TERMINATION CODE
      0910 1892      ;
      0910 1893      ;
      0910 1894      ; HERE, TREAT POWERFAIL AS TIMEOUT
      0910 1895      ;
      0910 1896      ;
      0910 1897      PWRFL1:
      0910 1898      ENBINT      ;ENABLE INTERRUPTS
      02DD 31 0913 1899      BRW      MSTMT01      ;GOTO TIMEOUT ROUTINE
      0916 1900      ;
      0916 1901      ; PXFR - CONSTRUCT COMMAND PACKET FOR DATA TRANSFER COMMANDS:
      0916 1902      ; READ NEXT(FORWARD), READ PREVIOUS(REVERSE), REREAD PREVIOUS(SPACE REV, READ
      0916 1903      ; FWD), REREAD NEXT(SPACE FWD, READ REV), WRITE DATA, WRITE DATA RETRY,
      0916 1904      ; AND WRITE SUBSYSTEM MEMORY.
      0916 1905      ;
      0916 1906      PXFRD:
      05 009A C5 09 E1 0916 1907      BBC      #IOSV_OPPOSITE, -      ; REREAD COMMANDS ENTER HERE.
      61 2000 8F AB 091C 1908      UCBSW_FUNC(R5), 10$      ; Branch if opposite bit not set.
      0A 11 0921 1909      BISW      #MS_CPHD_M_OPP, -      ; If its set, propagate it to the
      0923 1910      MS_CPHD(R1)      ; command header.
      0923 1911      10$:      BRB      PXFR      ; Then rejoin common code.
      0923 1912      ;
      0923 1913      PXFR:
      68 A5 20 AB 0923 1914      BISW      #UCBSM_MS_RDPR,UCBSW_DEVSTS(R5) ;FLAG BUFFERED DATAPATH
      0927 1915      REQDPR      ;REQUEST DATAPATH
      092D 1916      PXFR:      ;*ENTRY PT FOR READ REVERSE*
      092D 1917      ;**WHICH USES DIRECT DATA PATH**
      092D 1918      REQMPR      ;REQUEST MAP REGISTER
      0933 1919      LOADUBAA      ;LOAD MAP REGISTER
      50 09 09 34 A1 F0 0939 1920      MOVZWL      UCBSW_BOFF(R5),R0      ;GET BYTE OFFSET
      51 24 A5 D0 093D 1921      MOVL      UCBSL_CRB(R5),R1      ;GET CRB
      51 00B6 C5 D0 0941 1922      INSV      CRBSL_INTD+VE($SW_MAPREG(R1),#9,#9,R0 ;INSERT HGH 9 BITS
      02 A1 50 D0 0947 1923      MOVL      UCBSL_MS_TSPT1(R5),R1      ;GET COMMAND PACKET ADDR.
      06 68 A5 01 E0 094C 1924      MOVL      R0,MS_BACT(R1)      ;STORE XFR ADDR.
      0950 1925      BBS      #UCBSV_MS_SWAP,UCBSW_DEVSTS(R5),12$ ;BR IF INDUSTRIAL COMP.
      0955 1926      ; (SET BY SETCHAR COMMAND)
      05 009A C5 08 E1 0955 1927      BBC      #IOSV_SWAP,UCBSW_FUNC(R5),15$ ;SWAP BIT SET??
      61 1000 8F AB 0958 1928      12$:
      0958 1929      BISW      #MS_CPHD_M_SWB,MS_CPHD(R1) ;YES, SET IT IN CMD HEADER
      0960 1930      15$:
      06 A1 7E A5 D0 0960 1931      MOVW      UCBSW_BCNT(R5),MS_CNT(R1) ;STORE BYTE COUNT
      00C4 C5 7E A5 B0 0965 1932      MOVW      UCBSW_BCNT(R5),UCBSW_MS_XC(R5) ;COPY BYTE COUNT
      0968 1933      DSBINT      ;DISABLE INTERRUPTS
```

| | | |
|------------------------------|--------|---|
| 4B 64 A5 05 E0 0971 1934 | BBS | #UCBSV POWER,UCBSW_STS(R5),20\$;BR IF POWERFAILED |
| 64 00BE C5 B0 0976 1935 | MOVW | UCBSW_MS_TSP13(R5),(R4) ;LOAD THE COMMAND POINTER |
| | WFIKPC | MSTMO,#A20 ;TIMEOUT FOR 20. SEC.'S |
| | IOFORK | |
| 00000000'GF 16 0985 1937 | JSB | G*IOC\$PURGDATAP ;PURGE DATAPATH |
| 05 50 E8 0991 1939 | BLBS | R0,18\$;BR IF NO ERROR |
| 00C7 C5 01 90 0994 1940 | MOVB | #1,UCBSB_MS_PER(R5) ;MARK PURGE ERROR |
| | | |
| 26 64 A5 05 E0 0999 1942 | BBS | #UCBSV POWER,UCBSW_STS(R5),21\$;BR IF POWERFAILED |
| 00C4 C5 JOFC C5 A2 099E 1943 | ;; | WANT TO SAVE DATAPATH REG. & NO. & ETC. FOR ERRLOG |
| 00C4 C5 51 DO 099E 1944 | SUBW | UCBSW_MS_RBPC(R5),UCBSW_MS_XC(R5) ;GET BYTES ACTUALLY XFERRED |
| 37 A3 90 09AA 1946 | MOVL | R1,UCBSL_MS_DPR(R5) ;GET DATA PATH REGISTER |
| 00C6 C5 90 09AD 1947 | MOVB | CRBSL_INTD+VECSB_DATAPATH(R3),- |
| 51 7C A5 3C 09B0 1948 | MOVZWL | UCBSW_MS_DPN(R5) ;GET DATA PATH NO. |
| 00C6 C5 95 09B4 1949 | TSTB | UCBSB_BOFF(R5),R1 ;GET BYTE OFFSET |
| OD 12 09B8 1950 | BNEQ | 22\$;DATAPATH NO.=0(DIRECT)? |
| 51 00FC C5 A0 09BA 1951 | ADDW | UCBSW_MS_RBPC(R5),R1 ;NO |
| OB 11 09BF 1952 | BRB | 24\$;YES, REVERSE OPERATION |
| | | |
| | | 24\$;SKIP AROUND |
| | | |
| | | ;; HERE,TREAT POWERFAIL AS TIMEOUT |
| | | |
| | | 20\$: ENBINT ;ENABLE INTERRUPTS |
| | | |
| 0215 31 09C4 1960 | BRW | MSTMO |
| | | |
| | | 21\$: BRW MSTMO |
| | | |
| 51 00C4 C5 A0 09C7 1963 | | |
| | | 22\$: ADDW UCBSW_MS_XC(R5),R1 ;GET FINAL ADDR. OFFSET |
| | | |
| 51 51 F7 8F 78 09CC 1965 | | |
| 50 34 A3 3C 09D1 1967 | ASHL | #<-9>,R1,R1 ;MODULO 512 |
| 51 50 C0 09D5 1968 | MOVZWL | CRBSL_INTD+VECSW_MAPREG(R3),R0 ;MOVE START MAP REG. NO. |
| | ADDL | R0,R1 ;R1 HAS FINAL MAP REG. NO. |
| | | ;;R2 HAS START ADDR. OF 1ST MAP REGISTER |
| | | ;;R3 HAS CRB ADDRESS |
| | | ;; WHICH WERE GOTTEN FROM IOC\$PURGDATAP |
| 51 01EF 8F B1 09D8 1971 | | |
| | | ;;LEGAL MAP REG. NO.? |
| 1A 14 09DD 1973 | CMPL | #495,R1 |
| 51 01EF 8F 3C 09DF 1974 | BGTR | 25\$;BR IF YES |
| 00CC C5 6241 DO 09E4 1975 | MOVZWL | #495,R1 ;MAKE IT FINAL MAP REG. NO.=495 |
| 00D0 C5 FC A241 DO 09EA 1976 | MOVL | (R2)[R1],UCBSL_MS_FMPR(R5) ;SAVE FINAL MAP REG |
| 00D4 C5 6241 DO 09F1 1977 | MOVL | -4(R2)[R1],UCBSL_MS_PMPR(R5) ;SAVE PREVIOUS MAP REG |
| 1E 11 09F7 1978 | MOVL | (R2)[R1],UCBSL_MS_NMPR(R5) ;SAVE NEXT MAP REG(=495) |
| | BRB | 27\$;GO AHEAD NOW |
| | | |
| 00CC C5 6241 DO 09F9 1979 | | 25\$: ;LEGAL MAP REG. NO. |
| 00D0 C5 01 CE 09FF 1981 | MOVL | (R2)[R1],UCBSL_MS_FMPR(R5) ;SAVE FINAL MAP REG |
| 51 50 D1 0A04 1982 | MNEGL | #1,UCBSL_MS_PMPR(R5) ;ASSUME NO PREVIOUS MAP REG |
| 07 13 0A07 1983 | CMPL | R0,R1 ;WAS FINAL MAP REG. 1ST MAP REG |
| 00D0 C5 FC A241 DO 0A09 1984 | BEQL | 26\$;YES, THERE WAS NO PREVIOUS ONE |
| | MOVL | -4(R2)[R1],UCBSL_MS_PMPR(R5) ;OTHERWISE,SAVE PREVIOUS MAP REG |
| 00D4 C5 04 A241 DO 0A10 1985 | | |
| | | 26\$: MOVL 4(R2)[R1],UCBSL_MS_NMPR(R5) ;SAVE NEXT MAP REG |
| | | |
| 00C6 C5 95 0A17 1987 | | 27\$: TSTB UCBSB_MS_DPN(R5) ;TEST IF DIRECT DATAPATH? |
| OA 13 0A1B 1989 | BEQL | 30\$;YES |
| | | ;;RELEASE DATAPATH AND MAP REG.'S |
| | | |
| | | 0A1D 1990 |

```
68 A5 20 AA 0A1D 1991 RELDPR ;RELEASE DATA PATH
0A23 1992 BICW #UCBSM_MS_RDPR,UCBSW_DEVSTS(R5) ;CLEAR FLAG
0A27 1993 30$:
0A27 1994 RELMPR ;RELEASE MAP REGISTERS
0A2D 1995
0A2D 1996 BRB XTC1 ;
0A2F 1997
0A2F 1998
0A2F 1999
0A2F 2000 : XTC - PROCESS TERMINATION CODE
0A2F 2001 : HERE, THE FINAL STATUS CODE IS PUT IN R0, &
0A2F 2002 : THE DRIVE STATUS IS RECORDED INTO UCB
0A2F 2003 :
0A2F 2004 :
0A2F 2005 XTC:
0A2F 2006 TSTW UCBSW_MS_XC(R5) ;SHOULD ANYTHING XFERRED?
0A33 2007 BEQL XTC1 ;NO, BRANCH
00C4 C5 00FC C5 A2 0A35 2008 SUBW UCBSW_MS_RBPC(R5),UCBSW_MS_XC(R5) ;GET ACTUALLY XFERRED
0A3C 2009 XTC1:
0A3C 2010 BBC #MS_XSRO_V MOT,- ;DID TAPE MOVE?
0A3E 2011 UCBSW_MS_XSRO(R5),7$ ;BR IF NO
46 A5 07 AA 0A42 2012 BICW #<MTSM BOT!- ;CLEAR BOT, AND
0A46 2013 MTSM_EOF!- ;END OF FILE,
0A46 2014 MTSM_EOT>-16,UCBSL_DEVDEPEND+2(R5) ;END OF TAPE
0A46 2015 7$:
50 03 01 EF 0A46 2016 EXTZV #MS_TSSR_V TCC,#MS_TSSR_S_TCC,- ;EXTRACT TERMINATION CODE
00C2 C5 0A49 2017 UCBSW_MS_TSSR(R5),R0 ;INTO R0
0A4D 2018 CASE R0,- ;DISPATCH TO ROUTINES
0A4D 2019 100$,- ;NORMAL TERMINATION
0A4D 2020 110$,- ;ATTENTION CONDITION
0A4D 2021 120$,- ;TAPE STATUS SLERT
0A4D 2022 130$,- ;FUNCTION REJECT
0A4D 2023 140$,- ;RECOVERABLE ERROR(TAPE MOVED)
0A4D 2024 150$,- ;RECOVERABLE ERROR(TAPE NOT MOVED)
0A4D 2025 160$,- ;UNRECOVERABLE ERROR(TAPE POSI LOST)
0A4D 2026 170$,- ;FATAL CONTROLLER ERROR
0A4D 2027 >
0A61 2028 :
0A61 2029 : FATAL CONTROLLER ERROR(TCC=7)
0A61 2030 :
0A61 2031 :
0A61 2032 170$:
50 0054 8F 3C 0A61 2033 MOVZWL #SS$_CTRLERR,R0 ;PUT IN FINAL STATUS CODE
FD16 31 0A66 2034 BRW FATALERR ;GOTO FATAL ERROR
0A69 2035
0A69 2036 :
0A69 2037 : UNRECOVERABLE ERROR(TAPE POSITION LOST)
0A69 2038 : (TCC=6)
0A69 2039 :
0A69 2040 160$:
46 A5 10 AB 0A69 2041 BISW #<MTSM LOST-16>,UCBSL_DEVDEPEND+2(R5) ;MARK POSITION LOST
50 008C 8F 3C 0A6D 2042 MOVZWL #SS$_DRVERR,R0 ;PUT IN FINAL STATUS CODE
06 EO 0A72 2043 BBS #MS_XSRO_V ONL,- ;CHECK IF ON-LINE
05 00FE C5 0A74 2044 UCBSW_MS_XSRO(R5),165$ ;BR IF YES
50 01A4 8F 3C 0A78 2045 MOVZWL #SS$_MEDOFL,R0 ;NO, RETURN MEDIUM OFFLINE
FCFF 31 0A7D 2046 165$:
0A7D 2047 BRW FATALERR ;
```



```
0A80 2048
0A80 2049
0A80 2050 : NORMAL TERMINATION
0A80 2051 : (TCC=0)
0A80 2052
0A80 2053 100$:
50 01 3C 0A80 2054 MOVZWL #SS$ _NORMAL, R0 : PUT IN STATUS CODE
009C C5 02 C0 0A83 2055 101$:
009C D5 17 0A83 2056 ADDL #2, UCBS$ _DPC(R5) : ADJUST TO CORRECT RETURN ADDRESS
0A88 2057 JMP @UCBS$ _DPC(R5) : RETURN TO DRIVER
0A8C 2058
0A8C 2059 :
0A8C 2060 : ATTENTION CONDITION
0A8C 2061 : DRIVE HAS UNDERGONE STATUS CHANGE SUCH AS GOING OFFLINE OR COMING ONLINE
0A8C 2062 : (TCC=1)
0A8C 2063
0A8C 2064 110$:
06 06 06 E1 0A8C 2065 BBC #MS_XSR0_V_ONL, - : CHECK IF ONLINE?
00FE C5 0A8E 2066 UCBS$ _MS_XSR0(R5), 112$ : BR IF OFFLINE.
50 05 3C 0A92 2067 MOVZWL #TCC _REN, R0 : BECOME ONLINE, BUT
00B3 31 0A95 2068 BRW 150$ : SHOULDN'T HAVE BEEN OFFLINE
0A98 2069 112$:
50 0093 C5 90 0A98 2070 MOVB UCBS$ _CEX(R5), R0 : GET HARDWARE COMMAND INDEX
50 01 91 0A9D 2071 CMPB #CDHC _UNL, R0 : WAS IT UNLOAD?
DE 13 0AA0 2072 BEQL 100$ : YES, ITS OK
50 01A4 8F 3C 0AA2 2073 MOVZWL #SS$ _MEDOFFL, R0 : MARK AS MEDIUM OFFLINE
FCDS 31 0AA7 2074 BRW FATAERR : GOTO FATAL ERROR
0AAA 2075
0AAA 2076 :
0AAA 2077 : TAPE STATUS ALERT
0AAA 2078 : (BITS OF INTEREST: TMK, LET, RLS, EOT, RIB, AND RLL)
0AAA 2079 : **LET BIT IS LOGICAL END OF TAPE FOR DOS, NOT USED FOR NOW**
0AAA 2080 : (TCC=2)
0AAA 2081
0AAA 2082 :
0AAA 2083 : The reverse into BOT must return the status SS$ _NORMAL because
0AAA 2084 : at this time BACKUP depends on this fact and that is how the
0AAA 2085 : other tape drivers work. This has been modified again. So that the
0AAA 2086 : read reverse which BAKCUP doesn't depend on returns SS$ _ENDOFFILE
0AAA 2087 : when it encounters the BOT marker.
0AAA 2088
0AAA 2089 120$:
16 0104 C5 E1 0AAA 2090 BBC #MS_XSR3_V_RIB, - : REVERSE INTO BOT?
46 A5 01 A8 0AAC 2091 UCBS$ _MS_XSR3(R5), 121$ :
00B0 C5 D4 0AB0 2092 BISW #<MTSM BOT@-16>, UCBS$ _DEVDEPEND+2(R5) : YES
0092 C5 0F 91 0AB4 2093 CLRL UCBS$ _RECORD(R5)
C1 12 0AB8 2094 CMPB #CDHC _RDP, UCBS$ _FEX(R5) : Is this a read reverse?
50 0870 8F 3C 0ABD 2095 BNEQ 100$ : If NEQ then return NORMAL code
BD 11 0ABF 2096 MOVZWL #SS$ _ENDOFFILE, R0 : Take error return.
0AC4 2097 BRB 101$
0AC6 2098
0AC6 2099 121$:
07 00FE C5 E1 0AC6 2100 BBC #MS_XSR0_V_RLL, - : CHECK IF RECORD LENGTH LONG?
50 0838 8F 3C 0AC8 2101 UCBS$ _MS_XSR0(R5), 122$ : TAKE NORMAL RETURN, IF NOT
BD 11 0ACC 2102 MOVZWL #SS$ _DATAOVERUN, R0 : YES, ITS DATAOVERUN
0AD1 2103 BRB 101$ : TAKE NORMAL RETURN
0AD3 2104 122$:
```



```
21 00FE 0F E1 0AD3 2105 BBC #MS XSRO V TMK, - :CHECK IF SEE TAPE MARK
46 AS 02 AB 0AD5 2106 UCBSW MS-XSRO(R5),125$ :??
0092 C5 16 91 0ADD 2107 B1SW #<MTSM EOF@-16>,UCBSL_DEVDEPEND+2(R5) ;YES
16 13 0AE2 2108 CMPB #CDHC_QTM,UCBSB_FEX(R5) :WAS IT WRITE TMK?
0092 C5 05 91 0AE4 2109 BEQL 125$ :YES, LOOK FOR EOT
21 13 0AE9 2110 CMPB #CDHC_STR,UCBSB_FEX(R5) :WAS IT SKIPFILE REVERSE?
0092 C5 02 91 0AEB 2111 BEQL 128$ :YES
1A 13 0AF0 2112 CMPB #CDHC_STF,UCBSB_FEX(R5) :WAS IT SKIPFILE FORWARD?
3C 0AF2 2113 BEQL 128$ :YES
50 0870 BF 3C 0AF2 2114 MOVZWL #SS$_ENDOFFILE,R0 ***NOTE UCBSL RECORD WAS ADJUSTED**
FFB9 31 0AF7 2115 BRW 101$ :SET EOF
00 00FE C5 E1 0AFA 2116 125$: :TAKE NORMAL RETURN
46 AS 04 AB 0AFC 2117 BBC #MS XSRO V EOT, - :CHECK IF AT EOT?
50 0878 BF 3C 0B00 2118 B1SW #<MTSM EOT@-16>,UCBSL_DEVDEPEND+2(R5) ;YES, SET FLAG
FF77 31 0B04 2119 MOVZWL #SS$_ENDOFFTAPE,R0 :WRITE ERROR INTO EOT
FF71 31 0B09 2120 BRW 101$ ;
2121 128$: :ANYTHING ELSE?
2122 31 0B0C 2123 BRW 100$ :TAKE NORMAL RETURN**TEMP**
2124 0B0F 2124 :
2125 0B0F 2125 :
2126 0B0F 2126 :
2127 0B0F 2127 : FUNCTION REJECT
2128 0B0F 2128 : (BITS OF INTEREST:BOT,WLK,VCK,ONL,ILA,ILC,NEF,WLE)
2129 0B0F 2129 : (TCC=3)
2130 0B0F 2130 :
2131 0B0F 2131 130$:
50 008C BF 3C 0B0F 2132 MOVZWL #SS$_DRVERR,R0 :MARK AS DRIVE ERROR
01 E1 0B14 2133 BBC #MS XSRO V BOT, - :CHECK IF AT BOT
08 00FE C5 AB 0B16 2134 UCBSW MS-XSRO(R5),132$ :
46 AS 01 AB 0B1A 2135 B1SW #<MTSM BOT@-16>,UCBSL_DEVDEPEND+2(R5) ;YES
00B0 C5 D4 0B1E 2136 CLRL UCBSL_RECORD(R5)
04 E1 0B22 2137 132$: :
06 00FE C5 E1 0B22 2138 BBC #MS XSRO V VCK, - :WAS VOLUME CHECK?
68 AS 1000 BF AB 0B24 2139 UCBSW MS-XSRO(R5),134$ :
0B28 2140 B1SW #UCBSM_MS_VCK,UCBSW_DEVSTS(R5) ;YES,RECORD IT
0B2E 2141 134$:
08 E1 0B2E 2142 BBC #MS XSRO V WLE, - :CHECK IF WRITE LOCK ERROR
09 00FE C5 E1 0B30 2143 UCBSW MS-XSRO(R5),136$ :
46 AS 08 AB 0B34 2144 B1SW #<MTSM WOL@-16>,UCBSL_DEVDEPEND+2(R5) ;YES, SET FLAG
50 025C BF 3C 0B38 2145 MOVZWL #SS$_WRITLCK,R0 :MARK AS WRITE-LOCKED ERROR
0B3D 2146 136$:
06 E0 0B3D 2147 BBS #MS XSRO V ONL, - :CHECK IF ONLINE
05 00FE C5 E0 0B3F 2148 UCBSW MS-XSRO(R5),138$ :BR IF YES
50 01A4 BF 3C 0B43 2149 MOVZWL #SS$_MEDOFFL,R0 :MARK MEDIUM OFFLINE
FC34 31 0B48 2150 138$:
0B48 2151 BRW FATALERR :TAKE FATAL OR HARD ERROR RETURN
0B48 2152 :
0B48 2153 :
0B48 2154 : RECOVERABLE ERROR(TAPE MOVED)
0B48 2155 : RECOVERABLE ERROR(TAPE NOT MOVED)
0B48 2156 : (TCC=4 OR 5)
0B48 2157 :
0B48 2158 140$:
0B48 2159 :
0B48 2160 150$:
13 009A C5 0F E0 0B48 2161 BBS #IOBV_INHRETRY,UCBSW_FUNC(R5),155$ ;IF SET, RETRY INHIBITED
```

TSDRIVER
V04-000

H 6
- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00
HARDWARE COMMAND EXECUTOR 5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1

Page 46
(3)

| | | | | | | | | |
|------|------|----|----|------|------|--------|---------------------|-----------------------------------|
| 7E | 009C | D5 | 32 | 0B51 | 2162 | CVTBL | 0UCB\$DPC(R5) -(SP) | :GET BRANCH DISPLACEMENT |
| 009C | C5 | 8E | C0 | 0B56 | 2163 | ADDL | (SP)+,0CB\$DPC(R5) | :CALCULATE RETURN ADDRESS -2 |
| 009C | C5 | 02 | C0 | 0B58 | 2164 | ADDL | #2,UCB\$DPC(R5) | :ADJUST TO CORRECT RETURN ADDRESS |
| | 009C | D5 | 17 | 0B60 | 2165 | JMP | 0UCB\$DPC(R5) | :RETURN TO DRIVER |
| | | | | 0B64 | 2166 | | | |
| | FEFA | | 31 | 0B64 | 2167 | 155\$: | BRW | 170\$ |
| | | | | 0B67 | 2168 | | | :RETURN AS FATAL |

```
0B67 2170 .SBTTL TS11/TS04 INTERRUPT SERVICE ROUTINE
0B67 2171 .+
0B67 2172 .TS$INT - TS11/TS04 MAGTAPE INTERRUPTS
0B67 2173 .
0B67 2174 .THIS ROUTINE IS ENTERED VIA A JSB INSTRUCTION WHEN AN INTERRUPT OCCURS
0B67 2175 .ON TS11/TS04 CONTROLLER. THE STATE OF THE STACK ON ENTRY IS:
0B67 2176 .
0B67 2177 .      00(SP) = ADDR. OF IDB ADDRESS
0B67 2178 .      04-28(SP) = SAVED R0-R5
0B67 2179 .      32(SP) = INTERRUPT PC
0B67 2180 .      36(SP) = INTERRUPT PSL
0B67 2181 .
0B67 2182 .INTERRUPT DISPATCHING OCCURS AS FOLLOWS:
0B67 2183 .
0B67 2184 .(MUMBLE)
0B67 2185 .
0B67 2186 .-
0B67 2187 .
0B67 2188 .TS$INT::
0B67 2189 .      MOVL      @ (SP)+,R3          ;GET ADDR. OF IDB
0B6A 2190 .      MOVQ      IDB$C(CSR(R3),R4      ;GET CONTROLLER CSR AND UCB ADDR.
0B6D 2191 .      MOVL      UCB$C_MS_TSPT1(R5),R0    ;COMMAND PACKET ADDR. IN R0
0B72 2192 .      MOVW      (R4),UCB$C_MS_TSBA(R5)  ;GET DEVICE REGISTER TSBA(TSDB)
0B77 2193 .      MOVW      2(R4),UCB$C_MS_TSSR(R5) ;GET TSSR INTO UCB
0B7D 2194 .      BBCC      #UCB$V_INT,UCB$C_MS_TSSR(R5),10$ ;IF CLR, INTERRUPT NOT EXPECTED
0B82 2195 .      MOVW      MS_MHD(R0),UCB$C_MS_MHD(R5) ;SAVE MSG BUFFER IN UCB
0B88 2196 .      MOVL      MS_LNH(R0),UCB$C_MS_LNH(R5) ;SAVE NEXT LONG WORD
0B8E 2197 .      MOVQ      MS_XSR0(R0),UCB$C_MS_XSR0(R5) ;SAVE REST OF MSG BUFFER
0B94 2198 .      MOVL      UCB$C_FR3(R5),R3        ;RESTORE REMAINING DRIVER CONTEXT
0B98 2199 .      JSB       @UCB$C_FPC(R5)          ;CALL DRIVER
0B9B 2200 .      5$:
0B9B 2201 .      MOVQ      (SP)+,R0                ;RESTORE REGISTERS
0B9E 2202 .      MOVQ      (SP)+,R2
0BA1 2203 .      MOVQ      (SP)+,R4
0BA4 2204 .      REI
0BA5 2205 .      ;RETURN FROM INTERRUPT
0BA5 2206 .
0BA5 2207 .NON-QIO RESPONSE INTERRUPT
0BA5 2208 .
0BA5 2209 .
0BA5 2210 .10$:
0BA5 2211 .      BBSC      #UCB$V_MS_LBA,UCB$C_DEVSTS(R5),20$ ;YES. LOADING BUFFER ADDR.?
0BAA 2212 .      BRB       5$                          ; Branch to dismiss interrupt.
0BAC 2213 .
0BAC 2214 .
0BAC 2215 .      HERE, WAS LOADING BUFFER ADDRESS
0BAC 2216 .
0BAC 2217 .20$:
0BAC 2218 .      BBS        #MS_TSSR_V_NBA,-
0BAE 2219 .      UCB$C_MS_TSSR(R5),5$      ;FAIL TO LOAD BUFFER ADDR.
0B82 2220 .
0B82 2221 .      BUFFER ADDRESS LOADED SUCCESSFULLY
0B82 2222 .      DO RELEASE MESSAGE BUFFER TO TS11/TS04
0B82 2223 .
0B82 2224 .30$:
0B82 2225 .
0B82 2226 .      BISW      #<MTSM_BOT@-16>,UCB$C_DEVDEPEND+2(R5) ;MARK IT
```

| | | |
|------------------------------------|------|---|
| 1A 64 AS 05 E1 0BB6 2227 | BBC | #UCBSV_POWER,UCBSW_STS(R5),35\$;BR IF NOT POWERFAIL |
| 15 68 AS 0B E0 0BB8 2228 | BBS | #UCBSV_MS_RPI,UCBSQ_DEVSTS(R5),35\$;BR IF REPOSITION IN PROGRESS |
| 09 68 AS 06 E1 0BC0 2229 | BBC | #UCBSV_MS_SWE,UCBSW_DEVSTS(R5),34\$;BR IF NOT SOFTWARE EMULATION |
| 00F4 C5 00D0 C5 D0 0BC5 2230 | MOVL | UCBSL_MS_PMPR(R5),UCBSL_MS_TPOSITN(R5) ;GET FROM ELSEWHERE |
| 07 11 0BCC 2231 | BRB | 35\$ |
| 00F4 C5 00B0 C5 D0 0BCE 2232 34\$: | MOVL | UCBSL_RECORD(R5),UCBSL_MS_TPOSITN(R5) ;SAVE TAPE POSITION |
| 00B0 C5 D4 0BD3 2233 35\$: | CLRL | UCBSL_RECORD(R5) |
| FFBF 31 0BD9 2236 | BRW | 5\$ |
| 0BDC 2238 | | : WHICH TELL TAPE POSITION |
| 0BDC 2239 | | :DO RETURN FROM INTERRUPT |


```
OBDC 2241 .SBTTL TIMEOUT HANDLER
OBDC 2242 :+MSTMO - HANDLES TIME-OUT WHEN TS11/TS04 DOES NOT INTERRUPT AFTER
OBDC 2243 : A HARDWARE COMMAND ISSUED FOR A SPECIFIED PERIOD OF TIME.
OBDC 2244 : THE ROUTINE DEALLOCATES DATA PATH AND MAP REGISTER IF IT'S DATA
OBDC 2245 : TRANSFER COMMAND, AND ABORTS THE I/O OPERATION.
OBDC 2246 : IF IT WAS DUE TO POWERFAIL, REPOSITIONING IS ATTEMPTED, AND
OBDC 2247 : THE TIME-OUTED IRP IS RE-ISSUED
OBDC 2248 :
OBDC 2249 : INPUT:
OBDC 2250 :
OBDC 2251 : OUTPUT:
OBDC 2252 :
OBDC 2253 :
OBDC 2254 .ENABL LSB ;ENABLE LOCAL SYMBOL
OBDC 2255 MSTMO:
OBDC 2256 SETIPL UCBSB_FIPL(R5) ;LOWER IPL TO DEVICE FORK LEVEL
OBDC 2257 : **ASSUME NO PURGING OF DATAPATH FOR TIMEOUT**
06 68 A5 05 E5 OBEO 2258 BBCC #UCBSV_MS_RDPR,UCBSW_DEVSTS(R5),1$ ;BR IF DATAPATH NOT REQUESTED
OBEO 2259 1$: RELDPR ;RELEASE DATA PATH
OBEB 2260
OBEB 2261 RELMPR ;RELEASE MAP REGISTERS
04 11 OBF1 2262 BRB 2$
OBF3 2263 :
OBF3 2264 : TIMEOUT FOR NON-I/O XFR OPERATION
OBF3 2265 :
OBF3 2266 MSTMO1:
OBF3 2267 SETIPL UCBSB_FIPL(R5) ;LOWER IPL TO DEVICE FORK LEVEL
OBF7 2268 2$:
03 05 E4 OBF7 2269 BBSC #UCBSV_POWER,- ; Branch around to reposition if
03 64 A5 OBF9 2270 UCBSW_STS(R5),5$ ; we had POWERFAIL.
00CF 31 OBF9 2271 BRW 90$
OBF7 2272 :
OBF7 2273 : HERE, CHECK DRIVE OFF-LINE UNLOADED OR NOT
OBF7 2274 :
OBF7 2275 :
OBF7 2276 5$:
F5FE 30 OBF7 2277 BSBW TEST_NBA ; Test to assure we DON'T need TS11
OBF7 2278 ; message buffer address loaded.
03 50 E8 OC02 2279 BLBS P0,6$ ; LBS implies TS11 READY and able.
FB77 31 OC02 2280 BRW FATALERR ; If TS11 not ready, we can't even
OC02 2281 ; try to reposition.
OC02 2282 6$:
00000000'GF 16 OC02 2283 JSB G^EXES$READ_TODR ;GET CURRENT TIME OF DAY
50 000005DC 8F C0 OC02 2284 ADDL #1500,R0 ;ADD 15 SEC. TO WAIT
7C A5 50 D0 OC02 2285 MOVL R0,UCBSW_BOFF(R5) ;STORE IT IN UCB
OC02 2286 :
OC02 2287 : HERE, GET TS11'S CSR EQUIVALENT INTO R4
OC02 2288 :
OC02 2289 :
OC02 2290 7$:
OC02 2291 DSBINT ;DISABLE INTERRUPTS
OC02 2292 WFIKPC 8$,#2 ;WAITFOR INTERRUPT OR TIMEOUT
OC02 2293 IOFORK ;
OC02 2294 8$:
OC02 2295 SETIPL UCBSB_FIPL(R5) ;LOWER IPL TO FORK LEVEL
0020 31 OC02 2296 EXHC FAIL,RC_RWD ;DO A REWIND
OC02 2297 BRW 9$ ;BR IF SUCCESS=>DRIVE ONLINE
```

```

OC3E 2298 FAIL:
OC3E 2299 :
OC3E 2300 : HERE, TO SEND MESSAGE TO OPERATOR TO INFORM DRIVE OFFLINE
OC3E 2301 :
OC3E 2302 :
OC3E 2303 :
OC3E 2304 JSB G*EXES$READ TODR ;GET CURRENT TIME OF DAY
OC44 2305 RO,UCB$W_BOFF(R5) ;15 SEC. PASSED?
OC48 2306 BLEQU 78 ;NO, GO TRY AGAIN
OC4A 2307 :
OC4A 2308 MOVZBL #MSG$ DEVOFFLIN,R4 ;SET MESSAGE NUMBER
OC4E 2309 MOVAB G*SYS$GL OPRMBX,R3 ;GET ADDRESS OF OPERATOR MAILBOX
OC53 2310 JSB G*EXES$NDEVMSG ;SEND MESSAGE TO OPERATOR
OC5B 2311 BRW 68 ;
OC5E 2312 :
OC5E 2313 : OTHERWISE DO REPOSITIONING TAPE
OC5E 2314 :
OC5E 2315 :
OC5E 2316 9$:
OC5E 2317 BISW #UCB$M_MS_RPI,UCB$W_DEVSTS(R5) ;FLAG REPOSITION IN PROGRESS
OC64 2318 EXHC 50$,HC_RWD ;DO REWIND 1ST
OC6C 2319 ; & CLEAR UCB$L_RECORD
OC6C 2320 10$:
OC6C 2321 CMPL UCB$L_RECORD(R5),UCB$L_MS_TPOSITN(R5) ;CHECK REPOSITIONING
OC73 2322 BEQL 80$ ;BR IF YES
OC75 2323 CMPL UCB$L_RECORD(R5),UCB$L_MS_TPOSITN(R5) ;IS IT GTR THAN
OC7C 2324 BGTR 50$ ;BR IF YES
OC7E 2325 SUBL3 UCB$L_RECORD(R5),UCB$L_MS_TPOSITN(R5),RO ;GET WHAT'S LEFT
OC86 2326 CMPL #X7FFF,RO ;LESS THAN 32,768?
OC8D 2327 BGTR 20$ ;BR IF YES
OC8F 2328 MOVW #X7FFF,UCB$W_MS_SPACNT(R5) ;SKIP 32,768 RECORDS TILL DONE
OC96 2329 BRB 30$ ;
OC98 2330 20$:
OC98 2331 MOVW RO,UCB$W_MS_SPACNT(R5) ;SKIP WHAT'S LEFT
OC9D 2332 30$:
OC9D 2333 EXHC 50$,HC_SRF ;
OC9D 2334 MOVZWL UCB$W_MS_XC(R5),R1 ;GET NO. OF RECORDS PASSED
OC9D 2335 ADDL R1,UCB$L_RECORD(R5) ;UPDATE TAPE POSITION
OC9D 2336 BRB 10$ ;GO BACK
OC9D 2337 50$:
OC9D 2338 BICW #UCB$M_MS_RPI,UCB$W_DEVSTS(R5) ;CLEAR FLAG, REPOSI. FAILED
OC9D 2339 JMP FATALERO ;
OC9D 2340 :
OC9D 2341 : HERE, GO AHEAD WITH THE CURRENT QIO
OC9D 2342 :
OC9D 2343 80$:
OC9D 2344 BICW #UCB$M_MS_RPI,UCB$W_DEVSTS(R5) ;CLEAR FLAG, REPOSITION DONE
OC9D 2345 MOVL UCB$L_IRPTR(R5),R3 ;R3 HAS IRP ADDRESS
OC9D 2346 MOVQ IRP$S_SVAPTE(R3),UCB$S_SVAPTE(R5) ;RESTORE XFER PARAMETERS
OC9D 2347 JMP TS_STARTIO
OC9D 2348 90$:
OC9D 2349 JSB G*ERL$DEVICTMO ;LOG TIMEOUT ERROR
OC9D 2350 MOVZWL #SS$_TIMEOUT,RO ;SET TIMEOUT STATUS
OC9D 2351 .IF TS_TRACE
OC9D 2352 BSBW TRACE_STATUS ;Trace final I/O status.
OC9D 2353 .ENDC
OC9D 2354 REQCOM ;GO COMPLETE I/O REQUEST PROCESSING

```

TSDRIVER
V04-000

- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00 Page 51
TIMEOUT HANDLER 5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1 (3)

OCDF 2355
OCDF 2356

.DSABL LSB

```
OCDF 2358 .SBTTL TS11/TS04 REGISTER DUMP ROUTINE
OCDF 2359 +
OCDF 2360 : TS_REGDUMP - TS11/TS04 REGISTER DUMP ROUTINE
OCDF 2361 :
OCDF 2362 : THIS ROUTINE IS CALLED TO SAVE THE CONTROLLER AND DRIVE REGISTERS IN A
OCDF 2363 : SPECIFIED BUFFER. IT IS CALLED FROM THE DEVICE ERRORLOGGING ROUTINE AND
OCDF 2364 : FROM THE DIAGNOSTIC BUFFER FILL ROUTINE
OCDF 2365 :
OCDF 2366 : INPUT:
OCDF 2367 : R0 = ADDRESS OF REGISTER SAVE BUFFER
OCDF 2368 : R4 = ADDRESS OF CSR (EQUIVALENT)
OCDF 2369 : R5 = UCB ADDRESS
OCDF 2370 :
OCDF 2371 : OUTPUT:
OCDF 2372 :
OCDF 2373 : THE CONTROLLER AND DRIVE REGISTERS ARE SAVED IN THE SPECIFIED BUFFER
OCDF 2374 :
OCDF 2375 :
OCDF 2376 TS_REGDUMP:
80 80 17 DO OCDF 2377 MOVL #23,(R0)+ :23 REGISTERS FOLLOW TO BE DUMPED
80 00C0 C5 3C OCE2 2378 MOVZWL UCBSW_MS_TSBA(R5),(R0)+ :GET TSBA
80 00C2 C5 3C OCE7 2379 MOVZWL UCBSW_MS_TSSR(R5),(R0)+ :GET TSSR
80 00C6 C5 9A OCEC 2380 MOVZBL UCBSB_MS_DPN(R5),(R0)+ :GET DATAPATH NO.
80 00C8 C5 DO OCF1 2381 MOVL UCBSL_MS_DPR(R5),(R0)+ :GET DATAPATH REG.
80 00CC C5 DO OCF6 2382 MOVL UCBSL_MS_FMPR(R5),(R0)+ :GET FINAL MAP REGISTER
80 00D0 C5 DO OCFB 2383 MOVL UCBSL_MS_PMPR(R5),(R0)+ :GET FINAL-1 MAP REGISTER
80 00D4 C5 DO OD00 2384 MOVL UCBSL_MS_NMPR(R5),(R0)+ :GET FINAL+1 MAP REGISTER
51 00B6 C5 DO OD05 2385 MOVL UCBSL_MS_TSPT1(R5),R1 :GET MESSAGE BUFFER ADDR
52 0F 9A OD0A 2386 MOVZBL #15,R2 :15 WORDS IN MSG BUFFER
80 80 81 3C OD0D 2387 10$: MOVZWL (R1)+,(R0)+ :COPY FROM MSG BUFFER
FA 52 F5 OD10 2388 ;**FROM MS_CPHD TO MS_XSR3, SEE $DEFINI MS**
80 00C7 C5 9A OD10 2389 SOBGTR R2,10$ :LOOP-BACK
05 OD13 2391 MOVZBL UCBSB_MS_PER(R5),(R0)+ :GET PURGE ERROR INDICATOR
OD18 2392 RSB :
OD19 2393 TS_END: :ADDRESS OF LAST LOCATION IN DRIVER
OD19 2394
OD19 2395
OD19 2396 .END
```


TSDRIVER
Symbol table

B 7

- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00
5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1

Page 53
(3)

```

$$$ = 00000020 R 02
$$GP = 00000002
ACPSACCESS ***** X 03
ACPSDEACCESS ***** X 03
ACPSMODIFY ***** X 03
ACPSMOUNT ***** X 03
ACPSREADBLK ***** X 03
ACPSWRITEBLK ***** X 03
ATS_UBA = 00000001
CDHC_BRL = 00000019
CDHC_CLN = 00000018
CDHC_DRI = 00000004
CDHC_ERS = 00000006
CDHC_GST = 00000015
CDHC_NOP = 00000000
CDHC_PAK = 00000008
CDHC_RDN = 0000000C
CDHC_RDP = 0000000F
CDHC_RPS = 00000013
CDHC_RRN = 00000010
CDHC_RRP = 00000011
CDHC_RWD = 00000003
CDHC_SCH = 00000014
CDHC_SRF = 00000009
CDHC_SRR = 00000007
CDHC_STF = 00000002
CDHC_STR = 00000005
CDHC_UNL = 00000001
CDHC_WCK = 0000000A
CDHC_WDR = 00000012
CDHC_WKR = 0000000D
CDHC_WRC = 0000001B
CDHC_WRD = 0000000E
CDHC_WSM = 0000001A
CDHC_WTM = 00000016
CDHC_WTR = 00000017
CLEAR = 00000711 R 03
CLS_MDE = 00000003
CLS_MDF = 00000001
CLS_ONF = 00000000
CLS_OTHER = 00000001
CLS_PTB = 00000000
CLS_WLN = 00000002
CRBSL_INTD = 00000024
DCS_TAPE = 00000002
DDBSL_ACPD = 00000010
DDBSL_DDT = 0000000C
DEVSM_AVL = 00040000
DEVSM_DIR = 00000008
DEVSM_ELG = 00400000
DEVSM_FOD = 00004000
DEVSM_IDV = 04000000
DEVSM_NNM = 00000200
DEVSM_ODV = 08000000
DEVSM_SDI = 00000010
DEVSM_SQD = 00000020
DEVSV_FOR = 00000018

```

```

DEVSV_MNT = 00000013
DPTSC_LENGTH = 00000038
DPTSC_VERSION = 00000004
DPTSINITAB = 00000038 R 02
DPTSREINITAB = 00000076 R 02
DPTSTAB = 00000000 R 02
DRVCLR = 0000071C R 03
DTS_TS11 = 00000004
DYN$C_CRB = 00000005
DYN$C_DDB = 00000006
DYN$C_DPT = 0000001E
DYN$C_UCB = 00000010
EMBSL_DV_REGSARV = 0000004E
ERASE = 000006F0 R 03
ERL$DEVICERR ***** X 03
ERL$DEVICTMO ***** X 03
EXESALONONPAGED ***** X 03
EXESGL_NONPAGED ***** X 03
EXESIOFORK ***** X 03
EXESONEPARM ***** X 03
EXESREAD_TODR ***** X 03
EXESSETMODE ***** X 03
EXESSNDEVMSG ***** X 03
EXESZEROPARM ***** X 03
FAIL = 00000C3E R 03
FATALERO = 0000077A R 03
FATALERR = 0000077F R 03
FCC_CPE = 00000001
FCC_IDF = 00000000
FCC_LAP = 00000003
FCC_UPE = 00000002
FCNEXT = 00000795 R 03
FDISPATCH = 00000379 R 03
FUNCTAB_LEN = 00000088
GETSTS = 00000727 R 03
HCEX = 000007EF R 03
HCTAB = 00000038 R 03
HC_BRL = 0000C08A
HC_CLN = 0000C28A
HC_DRI = 0000C08B
HC_ERS = 0000C189
HC_GST = 0000C08F
HC_NOP = 00000000
HC_PAK = 00000000
HC_RDN = 0000C081
HC_RDP = 0000C181
HC_RPS = 00000000
HC_RRN = 0000C381
HC_RRP = 0000C281
HC_RWD = 0000C488
HC_SCH = 00000000
HC_SRF = 0000C088
HC_SRR = 0000C188
HC_STF = 0000C088
HC_STR = 0000C188
HC_UNL = 0000C18A
HC_WCK = 00000000

```

TUI
V04

TSDRIVER
Symbol table

- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00
5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1

Page 54
(3)

| | | | | | |
|------------------|------------|-----------------|------------|----|----|
| HC_WDR | = 0000C285 | IOCSLOADUBAMAPA | ***** | X | 03 |
| HC_WKR | = 00000000 | IOCSMNTVER | ***** | X | 03 |
| HC_WRC | = 0000C084 | IOCSPURGDATAP | ***** | X | 03 |
| HC_WRD | = 0000C085 | IOCSRELDATAP | ***** | X | 03 |
| HC_WSM | = 0000C086 | IOCSRELMAPREG | ***** | X | 03 |
| HC_WTM | = 0000C089 | IOCSREQCOM | ***** | X | 03 |
| HC_WTR | = 0000C289 | IOCSREQDATAP | ***** | X | 03 |
| IDBSL_CSR | = 00000000 | IOCSREQMAPREG | ***** | X | 03 |
| IDBSL_OWNER | = 00000004 | IOCSRETURN | ***** | X | 03 |
| IOSM_NOWAIT | = 00000080 | IOCSWFIKPC | ***** | X | 03 |
| IOSV_INHRETRY | = 0000000F | IRPSL_MEDIA | = 00000038 | | |
| IOSV_OPPOSITE | = 00000009 | IRPSL_SVAPTE | = 0000002C | | |
| IOSV_REVERSE | = 00000006 | IRPSL_WIND | = 00000018 | | |
| IOSV_SWAP | = 00000008 | IRPSF_FCODE | = 00000006 | | |
| IOS_ACCESS | = 00000032 | IRPSV_FCODE | = 00000000 | | |
| IOS_ACPCONTROL | = 00000038 | IRPSV_PHYSIO | = 00000008 | | |
| IOS_AVAILABLE | = 00000011 | IRPSV_VIRTUAL | = 00000004 | | |
| IOS_CLEAN | = 0000001E | IRPSW_FUNC | = 00000020 | | |
| IOS_CREATE | = 00000033 | IRPSW_STS | = 0000002A | | |
| IOS_DEACCESS | = 00000034 | LDTSD | 000008EB | R | 03 |
| IOS_DELETE | = 00000035 | MASKH | = 00000008 | | |
| IOS_DRVCLR | = 00000004 | MASKL | = 04000000 | | |
| IOS_ERASETAPE | = 00000006 | MEDIA_ID_TS11 | = 6CE9300B | | |
| IOS_MODIFY | = 00000036 | MMGSGC_SPTBASE | ***** | X | 03 |
| IOS_MOUNT | = 00000039 | MSDDT | 00000000 | RG | 03 |
| IOS_NOP | = 00000000 | MSG\$ DEVOFFLIN | ***** | X | 03 |
| IOS_PACKACK | = 00000008 | MSGREL | 000006FB | R | 03 |
| IOS_READBLK | = 00000021 | MSG_ATN | = 00000013 | | |
| IOS_READPBLK | = 0000000C | MSG_END | = 00000010 | | |
| IOS_READPRESET | = 00000019 | MSG_ERR | = 00000012 | | |
| IOS_READVBLK | = 00000031 | MSG_FAL | = 00000011 | | |
| IOS_RECAL | = 00000003 | MSG_LOG | = 00000014 | | |
| IOS_REREADN | = 00000016 | MSTMO | 00000BDC | R | 03 |
| IOS_REREADP | = 00000017 | MSTM01 | 00000BF3 | R | 03 |
| IOS_REWIND | = 00000024 | MS_BA1 | 00000004 | | |
| IOS_REWINDOFF | = 00000022 | MS_BACT | 00000002 | | |
| IOS_SENSECHAR | = 00000018 | MS_CHWD | 0000000E | | |
| IOS_SENSEMODE | = 00000027 | MS_CNT | 00000006 | | |
| IOS_SETCHAR | = 0000001A | MS_CPHD | 00000000 | | |
| IOS_SETMODE | = 00000023 | MS_CPHD_M_ACK | = 00008000 | | |
| IOS_SKIPFILE | = 00000025 | MS_CPHD_M_CVC | = 00004000 | | |
| IOS_SKIPRECORD | = 00000026 | MS_CPHD_M_IE | = 00000080 | | |
| IOS_SPACEFILE | = 00000002 | MS_CPHD_M_OPP | = 00002000 | | |
| IOS_SPACE RECORD | = 00000009 | MS_CPHD_M_SWB | = 00001000 | | |
| IOS_UNLOAD | = 00000001 | MS_LNH | 00000012 | | |
| IOS_VIRTUAL | = 0000003F | MS_LNTH | 0000000C | | |
| IOS_WRITECHECK | = 0000000A | MS_MBA0 | 00000008 | | |
| IOS_WRITEBLK | = 00000020 | MS_MBA1 | 0000000A | | |
| IOS_WRITE MARK | = 0000001C | MS_MHD | 00000010 | | |
| IOS_WRITEOF | = 00000028 | MS_RBPC | 00000014 | | |
| IOS_WRITEPBLK | = 0000000B | MS_TSSR_S_TCC | = 00000003 | | |
| IOS_WRITERET | = 00000018 | MS_TSSR_V_NBA | = 0000000A | | |
| IOS_WRITEVBLK | = 00000030 | MS_TSSR_V_SSR | = 00000007 | | |
| IOS_WRTMKR | = 0000001D | MS_TSSR_V_TCC | = 00000001 | | |
| IOCS CANCEL IO | ***** | MS_XSRO | 00000016 | | |
| IOCSDIAGBUFILE | ***** | MS_XSRO_V BOT | = 00000001 | | |
| IOCSLOADUBAMAP | ***** | MS_XSRO_V EOT | = 00000000 | | |

| SSS-VOL INVT | 00000254 | | |
|-----------------------|----------|----|----|
| SSS-WRITLCK | 0000025C | | |
| SYSSGL OPRMBX | ***** | X | 03 |
| TCC-ATN | 00000001 | | |
| TCC-FNR | 00000003 | | |
| TCC-FTL | 00000007 | | |
| TCC-NML | 00000000 | | |
| TCC-REM | 00000004 | | |
| TCC-REN | 00000005 | | |
| TCC-TSA | 00000002 | | |
| TCC-UER | 00000006 | | |
| TEST-NBA | 00000200 | R | 03 |
| TSSINT | 00000B67 | RG | 03 |
| TS-END | 00000D19 | R | 03 |
| TS-FUNCTABLE | 00000070 | R | 03 |
| TS-INIT | 000000F8 | R | 03 |
| TS-REGDUMP | 00000CDF | R | 03 |
| TS-STARTIO | 000002C1 | R | 03 |
| UCBSB-CEX | 00000093 | | |
| UCBSB-DEVCLASS | 00000040 | | |
| UCBSB-DEVTYPE | 00000041 | | |
| UCBSB-DIPL | 0000005E | | |
| UCBSB-ERTCNT | 00000080 | | |
| UCBSB-ERTMAX | 00000081 | | |
| UCBSB-FEX | 00000092 | | |
| UCBSB-FIPL | 0000000B | | |
| UCBSB-MS-DPN | 000000C6 | | |
| UCBSB-MS-PER | 000000C7 | | |
| UCBSK-LCC TAPE LENGTH | 000000B4 | | |
| UCBSK-MS-LENGTH | 00000106 | | |
| UCBSL-CRB | 00000024 | | |
| UCBSL-DEVCHAR | 00000038 | | |
| UCBSL-DEVCHAR2 | 0000003C | | |
| UCBSL-DEVDEPEND | 00000044 | | |
| UCBSL-DPC | 0000009C | | |
| UCBSL-FPC | 0000000C | | |
| UCBSL-FR3 | 00000010 | | |
| UCBSL-IOQFL | 0000004C | | |
| UCBSL-IRP | 00000058 | | |
| UCBSL-MEDIA ID | 0000008C | | |
| UCBSL-MS-DPR | 000000C8 | | |
| UCBSL-MS-FMPR | 000000CC | | |
| UCBSL-MS-NMPR | 000000D4 | | |
| UCBSL-MS-OMPR | 000000D8 | | |
| UCBSL-MS-PMPR | 000000D0 | | |
| UCBSL-MS-TIMOUT | 000000DC | | |
| UCBSL-MS-TMP2 | 000000E8 | | |
| UCBSL-MS-TPOSITN | 000000F4 | | |
| UCBSL-MS-TSPT1 | 000000B6 | | |
| UCBSL-MS-TSPT2 | 000000BA | | |
| UCBSL-RECORD | 000000B0 | | |
| UCBSL-SVAPTE | 00000078 | | |
| UCBSL-VCB | 00000034 | | |
| UCBSM-MS-FEF | 00000001 | | |
| UCBSM-MS-LBA | 00000400 | | |
| UCBSM-MS-RDPR | 00000020 | | |
| UCBSM-MS-RPI | 00000800 | | |

TSDRIVER
Symbol table

- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00 Page 56
5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1 (3)

| | | | | |
|---------------------|---|----------|---|----|
| UCBSM_MS_SWAP | = | 00000002 | | |
| UCBSM_MS_SWE | = | 00000040 | | |
| UCBSM_MS_VCK | = | 00001000 | | |
| UCBSM_ONLINE | = | 00000010 | | |
| UCBSM_VALID | = | 00000800 | | |
| UCBSQ_MS_BUF SVAPTE | | 000000EC | | |
| UCBSQ_MS_TMP1 | | 000000E0 | | |
| UCBSV_INT | = | 00000001 | | |
| UCBSV_MS_FEF | = | 00000000 | | |
| UCBSV_MS_LBA | = | 0000000A | | |
| UCBSV_MS_RDPR | = | 00000005 | | |
| UCBSV_MS_RPI | = | 0000000B | | |
| UCBSV_MS_SWAP | = | 00000001 | | |
| UCBSV_MS_SWE | = | 00000006 | | |
| UCBSV_MS_VCK | = | 0000000C | | |
| UCBSV_POWER | = | 00000005 | | |
| UCBSV_VALID | = | 0000000B | | |
| UCBSW_BCNT | = | 0000007E | | |
| UCBSW_BOFF | = | 0000007C | | |
| UCBSW_DEVBUSIZ | = | 00000042 | | |
| UCBSW_DEVSTS | = | 00000068 | | |
| UCBSW_FUNC | = | 0000009A | | |
| UCBSW_MS_LNH | | 000000FA | | |
| UCBSW_MS_MHD | | 000000F8 | | |
| UCBSW_MS_RBPC | | 000000FC | | |
| UCBSW_MS_SPACNT | | 000000B4 | | |
| UCBSW_MS_TSBA | | 000000C0 | | |
| UCBSW_MS_TSPT3 | | 000000BE | | |
| UCBSW_MS_TSSR | | 000000C2 | | |
| UCBSW_MS_XC | | 000000C4 | | |
| UCBSW_MS_XSR0 | | 000000FE | | |
| UCBSW_MS_XSR1 | | 00000100 | | |
| UCBSW_MS_XSR2 | | 00000102 | | |
| UCBSW_MS_XSR3 | | 00000104 | | |
| UCBSW_STS | = | 00000064 | | |
| UNLOAD | | 00000706 | R | 03 |
| VASS_VPN | = | 00000015 | | |
| VASV_VPN | = | 00000009 | | |
| VECSB_DATAPATH | = | 00000013 | | |
| VECSL_IDB | = | 00000008 | | |
| VECSL_UNITINIT | = | 00000018 | | |
| VECSW_MAPREG | = | 00000010 | | |
| WCBW_NMAP | = | 00000016 | | |
| WRITECHAR | | 00000507 | R | 03 |
| WRITECHECK | | 000003F1 | R | 03 |
| WRITECHECKR | | 000003F1 | R | 03 |
| WRITEDATA | | 000004A4 | R | 03 |
| WRITERET | | 000004F1 | R | 03 |
| WRITESUBS | | 000004FC | R | 03 |
| WRTTMK | | 00000698 | R | 03 |
| WRTTMKR | | 000006E5 | R | 03 |
| XTC | | 00000A2F | R | 03 |
| XTC1 | | 00000A3C | R | 03 |

! Psect synopsis !

| PSECT name | Allocation | PSECT No. | Attributes |
|--------------------|-------------------|-----------|---|
| . ABS . | 00000000 (0.) | 00 (0.) | NOPIC USR CON ABS LCL NOSHR NOEXE NORD NOWRT NOVEC BYTE |
| \$ABSS | 00000106 (262.) | 01 (1.) | NOPIC USR CON ABS LCL NOSHR EXE RD WRT NOVEC BYTE |
| \$\$\$105_PROLOGUE | 00000086 (134.) | 02 (2.) | NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE |
| \$\$\$115_DRIVER | 00000D19 (3353.) | 03 (3.) | NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG |

! Performance indicators !

| Phase | Page faults | CPU Time | Elapsed Time |
|------------------------|-------------|-------------|--------------|
| Initialization | 33 | 00:00:00.05 | 00:00:01.89 |
| Command processing | 120 | 00:00:00.39 | 00:00:03.56 |
| Pass 1 | 655 | 00:00:22.16 | 00:01:14.43 |
| Symbol table sort | 0 | 00:00:02.80 | 00:00:14.50 |
| Pass 2 | 410 | 00:00:05.50 | 00:00:22.91 |
| Symbol table output | 1 | 00:00:00.21 | 00:00:00.60 |
| Psect synopsis output | 0 | 00:00:00.01 | 00:00:00.01 |
| Cross-reference output | 0 | 00:00:00.00 | 00:00:00.00 |
| Assembler run totals | 1221 | 00:00:31.12 | 00:01:57.91 |

The working set limit was 2550 pages.
180605 bytes (353 pages) of virtual memory were used to buffer the intermediate code.
There were 140 pages of symbol table space allocated to hold 2533 non-local and 147 local symbols.
2396 source lines were read in Pass 1, producing 27 object records in Pass 2.
51 pages of virtual memory were used to define 49 macros.

! Macro library statistics !

| Macro library name | Macros defined |
|-------------------------------------|----------------|
| _\$255\$DUA28:[SYS.OBJ]LIB.MLB;1 | 32 |
| -\$255\$DUA28:[SYSLIB]STARLET.MLB;2 | 12 |
| TOTALS (all libraries) | 44 |

2529 GETS were required to define 44 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LIS\$:TSDRIVER/OBJ=OBJ\$:TSDRIVER MSRC\$:TSDRIVER/UPDATE=(ENH\$:TSDRIVER)+EXECMLS/LIB

0117 AH-BT13A-SE
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION
CONFIDENTIAL AND PROPRIETARY

